










SHEAR WALL SCHEDULE						
PANEL DESIGNATION	PLYWOOD/OSB	NAILING	FLOOR SILL PLATE ATTACHMENT (SEE NOTE 6)	FOUND. SILL BOLT SIZE AND SPACING (SEE NOTE 4)	MINIMUM NO. OF SILL BOLT PER 6'-0" WIDTH	REMARKS
	15/32"	10 <sup>d</sup> @6"O.C.	#12 W.S. @6" O.C.	5/8"∅ @24" O.C.	4	ONE SIDE
	15/32"	10 <sup>d</sup> @4"O.C.	#12 W.S. @4" O.C.	5/8"∅ @16" O.C.	5	ONE SIDE
	15/32"	10 <sup>d</sup> @3"O.C.	#12 W.S. @4" O.C.	5/8"∅ @16" O.C.	5	ONE SIDE
	15/32"	10 <sup>d</sup> @2"O.C.	#10 W.S. @3" O.C.	5/8"∅ @12" O.C.	6	ONE SIDE
	15/32"	10 <sup>d</sup> @4"O.C.	#10 W.S. @3" O.C.	5/8"∅ @8" O.C.	9	BOTH SIDES
	15/32"	10 <sup>d</sup> @3"O.C.	5/8" L.S. @4" O.C.	5/8"∅ @8" O.C.	9	BOTH SIDES
	15/32"	10 <sup>d</sup> @2"O.C.	5/8" L.S. @3" O.C.	5/8"∅ @6" O.C.	12	BOTH SIDES

**NOTES:**

- 3x STUDS AND TOP & BOTTOM PLATES REQUIRED TYPICAL EXCEPT FOR TYPE "A" WHERE 2x STUDS AND TOP & BOTTOM PLATES MAY BE USED. STAGGER NAILS INTO PLATES. USE 12" LONG ANCHOR BOLTS EXTENDING 4 1/2" OUT OF CONCRETE.
- WOOD STRUCTURAL PANEL SHALL BE APPLIED OVER STUDS @ 16"O.C. ON ONE SIDE OR BOTH SIDES OF STUD PER SCHEDULE ABOVE.
- NAILING AT INTERMEDIATE MEMBERS TO BE SPACED AT 12" O.C.
- ALL EXTERIOR FOOTINGS SHALL HAVE SILL BOLTS PER  (TYP. U.N.O.)

- FOR OTHER NOTES AND DETAILS SEE 
- WS = WOOD SCREW, LS = LAG SCREW
- PROVIDE 2"x2"x 3/16" PLATE WASHERS AT SILL BOLTS.
- MINIMUM PENETRATION OF WOOD SCREWS OR LAG SCREWS INTO FIRST FLOOR TOP PLATES OR NAILER ON STEEL BEAM IS GREATER OF 8x DIAMETER OR 2 1/2".