



New Options for Tall Timber Buildings in California: Understanding Codes and Design

Presented on 09/22/20 by Janelle Leafblad, PE

Photo: Kaiser+Path

Course Description

New tall mass timber code provisions approved for the 2021 International Building Code (IBC) will allow up to 18 stories of wood construction. The California Building Code (CBC) is also poised to permit tall timber buildings but following a slightly different path. In August of 2020, the California Building Standards Commission unanimously approved a series of code changes based on the new IBC provisions, but with California-specific modifications. Attendees will learn how tall wood buildings will be covered in both the 2021 IBC and the 2019 CBC. Starting with a review of the technical research and testing that supported the provisions, we'll then take a detailed look at the new code language and methods of addressing the requirements. Topics will include fire-resistance ratings and allowances for exposed timber, penetrations, sprinklers, connections, exterior walls, and more. Designers can expect to take away the knowledge they need to pursue tall wood projects.

Learning Objectives

1. Review the global history of tall wood construction and highlight the mass timber products used in these structures.
2. Explore the work and conclusions of the ICC Ad Hoc Committee on Tall Wood Buildings in establishing 14 new Group A and 3 new Group B code provisions for the 2021 IBC that address tall wood construction.
3. Discuss code-compliant options for exposing mass timber, where up to 2-hour fire-resistance ratings are required and demonstrate design methodologies for achieving these ratings.
4. Review code requirements unique to tall wood buildings, focusing on items such as sprinklers, shaft construction and concealed spaces.


Questions we'll answer:

- What is tall wood?
- How tall is tall?
- What has been done?
- What wood products are used in tall wood?
- What does the Code allow now?
- How did we arrive at the proposed tall wood code changes?
- What are the new tall wood code provisions?



TALL WOOD IN NORTH AMERICA CIRCA 1906

9 STORIES



GLOBAL TALL WOOD CIRCA 2015

7-14 STORIES



GLOBAL TALL WOOD CIRCA 2019

18-24 STORIES



TALL WOOD IN THE US CIRCA 2019

8 STORIES




Photos: Baumberger Studio/PATH Architecture/Marcus Kauffman | Architect: PATH Architecture



HEAVY TIMBER

Federal Center South, Seattle, WA
Photo: Benjamin Benschneider



MASS TIMBER

Bullitt Center, Seattle, WA
Photo: John Stamets

GLULAM



CROSS-LAMINATED TIMBER (CLT)



NAIL-LAMINATED TIMBER (NLT)



Photo: Think Wood



Photo: StructureCraft



Photo: LendLease



Photo: Ema Peter

DOWEL-LAMINATED TIMBER (DLT)



Photo: StructureCraft

MASS PLYWOOD PANELS (MPP)



DECKING



Photo: StructureCraft



Photo: LEVER Architecture



Photo: Bernard André Photography

OFFICES | MULTI-FAMILY | COMMERCIAL | EDUCATIONAL



Photo: JC Buck



Photo: William Horne



Photo: LEVER Architecture



Photo: David Sundberg and Gray
Organschi Architecture



Photo: Christian Columbres

A low-angle, upward-looking shot of a wooden staircase. The stairs are made of light-colored wood and have a dark metal railing. The perspective creates a sense of height and depth. Bright, rectangular overhead lights are visible on the right side of the frame, casting a strong glow. The background shows more of the staircase and some structural elements of the building.

WHY TALL WOOD?


GLOBAL POPULATION BOOM



Global Population
7.6 billion now
9.8 billion by 2050
30% increase

Source: United Nations Department
of Economic and Social Affairs

Urban and rural population
United States of America
■ Urban ■ Rural



US URBAN POPULATION BOOM



URBAN



RURAL

2019

271 M

57.7 M

2030

301 M

53.7 M

2050

347 M

42.2 M



Construction Traffic & Noise

Material Stockpiles

Labor Costs

Labor Availability

Weather Risks



Resiliency

Sustainability

Fire & Life Safety




MARKET DRIVERS FOR MASS TIMBER

PRIMARY DRIVERS

- » Construction efficiency & speed
- » Construction site constraints – urban infill
- » Innovation/Aesthetics

SECONDARY DRIVERS

- » Carbon reductions
- » Structural performance – lightweight



ESTIMATED ENVIRONMENTAL IMPACT OF WOOD USE



Volume of wood products used:
2,233 cubic meters of CLT and Glulam



U.S. and Canadian forests grow this much wood in:
6 minutes



Carbon stored in the wood:
1,753 metric tons of CO₂



Avoided greenhouse gas emissions:
679 metric tons of CO₂



Total potential carbon benefit:
2,432 metric tons of CO₂

THE ABOVE GHG EMISSIONS ARE EQUIVALENT



511 cars off the road for a year



Energy to operate a home for 222 years

**Estimated by the Wood Carbon Calculator for Buildings, based on research by Sathre, R. and J. O'Connor, 2010, A Synthesis of Research on Wood Products and Greenhouse Gas Impacts, FPInnovations (this relates to carbon stored and avoided GHG).*

**CO2 in this case study refers to CO2 equivalent*

Source: Naturally:Wood9



Reduced Embodied Carbon

Brock Commons, Vancouver, BC

Photo Credit: UBC



TALL WOOD IN THE U.S.


- 
- » **Current Prescriptive Code Limit - 6 stories (B occupancy) or 85 feet**
 - » **Over 6 Stories - Alternate Means and Materials Request (AMMR) through performance-based design**
 - » **Based on the 1910 Heights and Areas Act**



Photo: Blaine Brownell



Photo: Christian Columbres



ICE Block I, RMW Architecture & Interiors, Buehler Engineering, Bernard André Photography



Photo: Swinerton



U.S. BUILDING CODE STATUS


Photo: Ema Peter

U.S. TALL WOOD DEVELOPMENT AND CHANGES

Seen as the catalyst for the mass timber revolution, CLT IS first recognized in US codes in the 2015 IBC

[BS] CROSS-LAMINATED TIMBER. A prefabricated engineered wood product consisting of not less than three layers of solid-sawn lumber or *structural composite lumber* where the adjacent layers are cross oriented and bonded with structural adhesive to form a solid wood element.

2303.1.4 Structural glued cross-laminated timber. Cross-laminated timbers shall be manufactured and identified in accordance with ANSI/APA PRG 320.



U.S. TALL WOOD DEVELOPMENT AND CHANGES

Interest in tall wood projects in the US was rapidly increasing. Some building officials were reluctant to approved proposed plans, primarily due to lack of code direction and precedent



Empire State Building, New York City, New York, 1931



Photo: Seagate Structures

UBC Brock Commons Student Residence, Vancouver, British Columbia, 2016

U.S. TALL WOOD DEVELOPMENT AND CHANGES



In December 2015, the ICC Board established the ICC Ad Hoc Committee (AHC) on Tall Wood Buildings. Objectives:

1. Explore the building science of tall wood buildings
2. Investigate the feasibility of tall wood buildings
3. Take action on developing code changes for tall wood buildings

Taller wood buildings create new set of challenges to address:

AHC established 6 performance objectives:

1. No collapse under reasonable scenarios of complete burn-out of fuel without automatic sprinkler protection being considered.
2. Highly reliable fire suppression systems to reduce the risk of failure during reasonably expected fire scenarios. The degree of reliability should be proportional to evacuation time (height) and the risk of collapse.



Performance Objectives

3. No unusually high radiation exposure from the subject building to adjoining properties to present a risk of ignition under reasonably severe fire scenarios.
4. No unusual response from typical radiation exposure from adjacent properties to present a risk of ignition of the subject building under reasonably severe fire scenarios.



Performance Objectives

- 5. No unusual fire department access issues.
- 6. Egress systems designed to protect building occupants during the design escape time, plus a factor of safety.



Photo: Will Pryce



U.S. BUILDING CODES

Tall Wood Ad Hoc Committee

Commissioned series of 5 full-scale tests on 2-story mass timber structure at ATF lab in MD, May-June 2017




Figure 2. Elevation view of the front of the cross-laminated timber test structure.




Figure 1. General plan view of cross-laminated timber test structure.

U.S. BUILDING CODES

Tall Wood Ad Hoc Committee

Test	Description	Construction Type
Test 1	All mass timber surfaces protected with 2 layers of 5/8" Type X Gypsum. No sprinklers.	IV-A
Test 2	30% of CLT ceiling area in living room and bedroom exposed. No sprinklers.	IV-B
Test 3	Two opposing CLT walls exposed – one in bedroom and one in living room. No sprinklers.	IV-B
Test 4	All mass timber surfaces fully exposed in bedroom and living room. Sprinklered – normal activation.	IV-C
Test 5	All mass timber surfaces fully exposed in bedroom and living room. Sprinklered – 20 minute delayed activation.	IV-C



Photo: LendLease



Photo: LendLease



Photo: LendLease



Photo: LendLease



Photo: LendLease

Although not directly affiliated with the TWB AHC, other mass timber and tall wood testing & research was occurring, the results of which the AHC included in their final decisions



RESEARCH FOUNDATION

RESEARCH FOR THE NFPA MISSION



Fire Safety Challenges of Tall Wood Buildings – Phase 2: Task 5 – Experimental Study of Delamination of Cross Laminated (CLT) Timber in Fire

SOUTHWEST RESEARCH INSTITUTE®

1228 CULEBRA ROAD • 78228-5166 • P.O. DRAWER 28510 • 78228-0510 • SAN ANTONIO, TEXAS, USA • (210) 684-5111 • WWW.SWRI.ORG

CHEMISTRY AND CHEMICAL ENGINEERING DIVISION

FIRE TECHNOLOGY DEPARTMENT
WWW.FIRE.SWRI.ORG
FAX (210) 522-3377



DEVELOPMENT OF A FIRE PERFORMANCE ASSESSMENT
METHODOLOGY FOR QUALIFYING CROSS-LAMINATED
TIMBER ADHESIVES



WESTERN FIRE CENTER, INC.

2204 Parrott Way, Kelso, Washington 98626
Phone: 360-423-1400 | Fax: 360-423-5003

Fire Resistance Testing of CLT Floor/Ceiling
Assemblies to Establish Contribution of
Gypsum Protection

U.S. BUILDING CODES

DEVELOPMENT AND CHANGES

ICC TWB Ad Hoc Committee Group A proposals consisted of the following 14 parts:

Requirements for the new Types of Construction:

- IBC Section 602.4 – Type of Construction (G108-18)
- IBC Section 703.8 – Performance Method for Fire Resistance from Noncombustible Protection (FS5-18)
- IBC Section 722.7 – Prescriptive Fire Resistance from Noncombustible Protection (FS81-18)
- IBC Section 703.9 – Sealants at Edges (FS6-18)
- IBC Section 718.2.1 – Fire and Smoke Protection (FS73-18)
- IBC Section 403.3.2 – High-Rise Sprinkler Water Supply (G28-18)
- IBC Section 701.6 – Owners' Responsibility (F88-18)
- IFC Section 3308.4 – Fire Safety During Construction (F266-18)

Allowable building size limits:

- IBC Table 504.3 – Building Height (G75-18)
- IBC Table 504.4 – Number of Stories (G80-18)
- IBC Table 506.2 – Allowable Area (G84-18)

Housekeeping changes:

- IBC Section 3102 – Special Construction (G146-18)
- IBC Appendix D – Fire Districts (G152-18)
- IBC Section 508.4 and 509.4 – Fire Barriers (G89-18)

TALL WOOD APPROVED!

Unofficial results posted Dec. 19, 2018

Final votes ratified Jan. 31, 2019

AWC: Tall Mass Timber code changes get final approval

Dec 19, 2018

LEESBURG, VA. – The International Code Council (ICC) has released the unofficial voting results on code change proposals considered in 2018, including passage of the entire package of 14 tall mass timber code change proposals. The proposals create three new types of construction (Types IV-A, IV-B and IV-C), which set fire safety requirements, and allowable heights, areas and number of stories for tall mass timber buildings. Official results are expected to be announced during the first quarter of 2019. The new provisions will be included in the 2021 *International Building Code* (IBC).

"Mass timber has been capturing the imagination of architects and developers, and the ICC result means they can now turn sketches into reality. ICC's rigorous study, testing and voting process now recognizes a strong, low-carbon alternative to traditional tall building materials used by the building

SO WHAT'S CHANGED??



Since its debut, IBC has contained 9 construction type options

5 Main Types (I, II, III, IV, V) with all but IV having sub-types A and B

TYPE I		TYPE II		TYPE III		TYPE IV	TYPE V	
A	B	A	B	A	B	HT	A	B

Three Main Categories:

1. Noncombustible (Types I and II)
2. Light-Frame (Types III and V)
3. **Heavy/Mass Timber (Type IV)**

Use of heavy/mass timber products in low- to mid-rise buildings of Types III and V construction is very common

2021 IBC Introduces 3 new tall wood construction types:

IV-A, IV-B, IV-C

Previous type IV renamed type IV-HT

BUILDING ELEMENT	TYPE I		TYPE II		TYPE III		TYPE IV				TYPE V	
	A	B	A	B	A	B	A	B	C	HT	A	B

New Building Types



18 STORIES
BUILDING HEIGHT 270'
ALLOWABLE BUILDING AREA 972,000 SF
AVERAGE AREA PER STORY 54,000SF

TYPE IV-A



12 STORIES
BUILDING HEIGHT 180 FT
ALLOWABLE BUILDING AREA 648,000 SF
AVERAGE AREA PER STORY 54,000SF


TYPE IV-B



9 STORIES
BUILDING HEIGHT 85'
ALLOWABLE BUILDING AREA 405,000 SF
AVERAGE AREA PER STORY 45,000 SF

TYPE IV-C

IBC 2021



6 STORIES MAXIMUM
85'-0" MAXIMUM BUILDING HEIGHT
324,00 SF MAXIMUM AREA

TYPE IV- HT

IBC 2015

BUSINESS OCCUPANCY [GROUP B]

*BUILDING FLOOR-TO-FLOOR HEIGHTS ARE SHOWN AT 12'-0" FOR ALL EXAMPLES FOR CLARITY IN COMPARISON BETWEEN 2015 TO 2021 IBC CODES.

Type IV-A



18 STORIES
BUILDING HEIGHT 270'
ALLOWABLE BUILDING AREA 972,000 SF
AVERAGE AREA PER STORY 54,000SF


TYPE IV-A

Credit: Susan Jones, atelierjones



Photos: Structurlam, naturally:wood,
Fast + Epp, Urban One


Type IV-A Protection vs. Exposed



18 STORIES
BUILDING HEIGHT 270'
ALLOWABLE BUILDING AREA 972,000 SF
AVERAGE AREA PER STORY 54,000SF

TYPE IV-A

Credit: Susan Jones, atelierjones



100% NC protection on all surfaces of Mass Timber

Credit: Acton Ostry Architects, Fast + Epp

Type IV-A Height and Area Limits



18 STORIES
BUILDING HEIGHT 270'
ALLOWABLE BUILDING AREA 972,000 SF
AVERAGE AREA PER STORY 54,000SF

TYPE IV-A

Occupancy	# of Stories	Height	Area per Story	Building Area
A-2	18	270 ft	135,000 SF	405,000 SF
B	18	270 ft	324,000 SF	972,000 SF
M	12	270 ft	184,500 SF	553,500 SF
R-2	18	270 ft	184,500 SF	553,500 SF

Areas exclude potential frontage increase

Different in the CBC

In most cases, Type IV-A height & story allowances = $1.5 \times$ Type I-B height & story allowances

Type IV-A area = $3 \times$ Type IV-HT area

Type IV-B



12 STORIES
BUILDING HEIGHT 180 FT
ALLOWABLE BUILDING AREA 648,000 SF
AVERAGE AREA PER STORY 54,000SF

TYPE IV-B

Credit: Susan Jones, atelierjones



Credit: LEVER Architecture



Type IV-B Protection vs. Exposed



12 STORIES
BUILDING HEIGHT 180 FT
ALLOWABLE BUILDING AREA 648,000 SF
AVERAGE AREA PER STORY 54,000SF

TYPE IV-B

Credit: Susan Jones, atelierjones



Credit: Kaiser+Path

NC protection on all surfaces of Mass Timber except limited exposed areas
≈20% of ceiling or ≈40% of wall can be exposed, see code for requirements

Type IV-B Height and Area Limits



12 STORIES
BUILDING HEIGHT 180 FT
ALLOWABLE BUILDING AREA 648,000 SF
AVERAGE AREA PER STORY 54,000SF

TYPE IV-B

Occupancy	# of Stories	Height	Area per Story	Building Area
A-2	12	180 ft	90,000 SF	270,000 SF
B	12	180 ft	216,000 SF	648,000 SF
M	8	180 ft	123,000 SF	369,000 SF
R-2	12	180 ft	123,000 SF	369,000 SF

Areas exclude potential frontage increase

Different in the CBC

In most cases, Type IV-B height & story allowances = Type I-B height & story allowances

Type IV-B area = 2 × Type IV-HT area

Type IV-C



9 STORIES
BUILDING HEIGHT 85'
ALLOWABLE BUILDING AREA 405,000 SF
AVERAGE AREA PER STORY 45,000 SF

TYPE IV-C



Credit: Susan Jones, atelierjones

Photos: Baumberger Studio/PATH
Architecture/Marcus Kauffman

Type IV-C Protection vs. Exposed



9 STORIES
BUILDING HEIGHT 85'
ALLOWABLE BUILDING AREA 405,000 SF
AVERAGE AREA PER STORY 45,000 SF

TYPE IV-C

Credit: Susan Jones, atelierjones



Credit: Kaiser+Path, Ema Peter

All Mass Timber surfaces may be exposed

Exceptions: Shafts, concealed spaces, outside face of exterior walls

Type IV-C Height and Area Limits



9 STORIES
 BUILDING HEIGHT 85'
 ALLOWABLE BUILDING AREA 405,000 SF
 AVERAGE AREA PER STORY 45,000 SF

TYPE IV-C

Occupancy	# of Stories	Height	Area per Story	Building Area
A-2	6	85 ft	56,250 SF	168,750 SF
B	9	85 ft	135,000 SF	405,000 SF
M	6	85 ft	76,875 SF	230,625 SF
R-2	8	85 ft	76,875 SF	230,625 SF


Areas exclude potential frontage increase

Different in the CBC

In most cases, Type IV-C height allowances = Type IV-HT height allowances, but add 1 stories permitted due to enhanced FRR

Type IV-C area = $1.25 \times$ Type IV-HT area

Tall Wood Fire Resistance Ratings (FRR)



Primary Frame or Brg Wall FRR

Floor Construction FRR


Roof Construction FRR

Floor Surface Protection

Roof Construction Protection

3 HR (2 HR at Roof)	2 HR (1 HR at Roof)	2 HR (1 HR at Roof)
2 HR	2 HR	2 HR
1.5 HR	1 HR	1 HR
1 inch of NC protection on top	1 inch of NC protection on top	No protection req.'d
2 layers 5/8" Type X gyp. on underside	2 layers 5/8" Type X gyp. on underside	No protection req.'d unless concealed space

Tall Wood Materials & Protection



Exterior Walls

Structural Materials

Concealed Spaces

Gypsum Protection

If Mass Timber, exterior surface protected with 1 layer 5/8" Type X gyp.

Mass Timber or NC

Permitted, requires NC protection on MT surfaces

All MT is protected
3 HR: 3 layers 5/8"
Type X gyp.
2 HR or less: 2 layers
5/8" Type X gyp.

Same as IV-A for
protected MT. Limited
exposed MT
permitted, FRR still
applies

All MT permitted may
be exposed except as
noted

Tall Wood Buildings in the 2021 IBC

Up to 18 Stories of Mass Timber

Scott Brannen, PhD, SE, WoodWorks - Wood Products Council • Matt Timmers, SE, John A. Martin & Associates
• Dennis Richardson, PE, CBO, CAsp, American Wood Council

In January 2019, the International Code Council (ICC) approved a set of proposals to allow tall wood buildings as part of the 2021 International Building Code (IBC). Based on these proposals, the 2021 IBC will include three new construction types—Type IV-A, IV-B and IV-C—allowing the use of mass timber or noncombustible materials. These new types are based on the previous Heavy Timber construction type (renamed Type IV-HT) but with additional fire-resistance ratings and levels of required noncombustible protection. The code will include provisions for up to 18 stories of Type IV-A construction for Business and Residential Occupancies.

Based on information first published in the Structural Engineers Association of California (SEAOC) 2018 Conference Proceedings, this paper summarizes the background to these proposals, technical research that supported their adoption, and resulting changes to the IBC and product-specific standards.

Background: ICC Tall Wood Building Ad Hoc Committee

Over the past 10 years, there has been a growing interest in tall buildings constructed from mass timber materials (Brannen 2013, Timmers 2015). Around the world there



WoodWorks Tall Wood Design Resource

http://www.woodworks.org/wp-content/uploads/wood_solution_paper-TALL-WOOD.pdf


PROCEEDINGS			
Via Carrini	Milan, Italy	9	2013



An aerial photograph of a tall building under construction. The structure features a complex wooden post-and-beam framework, with numerous vertical wooden columns and horizontal beams. The building is surrounded by other urban structures and greenery. A semi-transparent white banner with the text "EARLY TALL WOOD CODE ADOPTION IN CALIFORNIA" is overlaid across the center of the image.

EARLY TALL WOOD CODE ADOPTION IN CALIFORNIA

CALIFORNIA AGREES TO EARLY ADOPTION OF TALL WOOD PROVISIONS



California Building Standards Commission Passes Tall Wood Code Change Proposals

Source: Softwood Lumber Board

On August 13, 2020 the California Building Standards Commission grouped the tall wood code change proposals into one agenda item and passed them unanimously.

The changes will be published as an amendment to the 2019 CBC on January 1, 2021 and will become effective on July 1, 2021.

California Building Standards Commission Passes Tall Wood Code Change Proposals

Source: Softwood Lumber Board

"The early adoption of mass timber codes can be a benefit to California in many ways, but I would like to highlight three of those advantages in this proposal.

- 1. It has the potential to **increase the market demand for mass timber production in California** to meet the needs of the construction industry.*
- 2. It will **increase the pace and scale of our wildland fire prevention and forest management goals** of treating 500 thousand acres per year by thinning the forest of smaller diameter trees that can be used in the production of cross laminated timber and other mass timber assemblies.*
- 3. While wood products provide the benefit of storing carbon, another benefit or advantage is that **mass timber construction can also help reduce the carbon footprint** of concrete and steel production."*


– Chief Mike Richwine, State Fire Marshal

CBC Tall Wood Building Size Limits

The CBC has historically not allowed “double-dipping” for sprinkler increases of building height and area for A, E, H, I, L or R occupancies. The IBC has no such restriction.


Also specific to the CBC, for multi-story buildings that are A, E, H, I, L or R occupancies, the total allowable building area is equal to the allowable floor area multiplied by the number of stories, not to exceed 2. In the IBC, this value is 3 for all occupancies.

This is also the case for Tall Wood.



Larger Area

VS.



Taller

CBC Tall Wood Building Size Limits

For example, if using the sprinkler area increases, the allowable height in the CBC is 20 ft and 1 story less than the IBC limits for Type IV-A, IV-B and IV-C construction for A, E, H-4, I-4, R-1 and R-2 occupancies.



OCCUPANCY CLASSIFICATION	TYPE OF CONSTRUCTION				
	SEE FOOTNOTES	TYPE IV			
		<u>A</u>	<u>B</u>	<u>C</u>	HT
B, F, M, S, U	NS ^b	<u>65</u>	<u>65</u>	<u>65</u>	65
	S	<u>270</u>	<u>180</u>	<u>85</u>	85
A, E	NS ^b	<u>65</u>	<u>65</u>	<u>65</u>	65
	<i>S (without area increase)</i>	<u>270</u>	<u>180</u>	<u>85</u>	85
	<i>S (with area increase)</i>	<u>250</u>	<u>160</u>	<u>65</u>	65

CBC Tall Wood Building Size Limits

	Construction Type (<u>Sprinklered Values</u>)						
	I-A	I-B	<u>IV-A</u>	<u>IV-B</u>	<u>IV-C</u>	IV-HT	III-A
Occupancies	Allowable Building Height above Grade Plane, Feet (CBC Table 504.3)						
B, F, M, S, U, R-3, R-4	Unlimited	180*	<u>270</u>	<u>180</u>	<u>85</u>	85	85
A, E, R-1, R-2 (w/ area increase)	Unlimited	180 (160)	<u>270</u> (250)	<u>180</u> (160)	<u>85</u> (65)	85 (65)	85 (65)
	Allowable Number of Stories above Grade Plane (CBC Table 504.4)						
A-2, A-3, A-4 (w/ area increase)	Unlimited	12 (11)	<u>18</u> (17)	<u>12</u> (11)	<u>6</u> (5)	4 (3)	4 (3)
B	Unlimited	12	<u>18</u>	<u>12</u>	<u>9</u>	6	6
R-1, R-2 (w/ area increase)	Unlimited	12 (11)	<u>18</u> (17)	<u>12</u> (11)	<u>8</u> (7)	5 (4)	5 (4)
	Allowable Area Factor (At) for SM, Feet ² (CBC Table 506.2)						
A-1, A-2, A-3, A-4 (w/ height increase)	Unlimited	Unlimited	<u>135,000</u> (45,000)	<u>90,000</u> (30,000)	<u>56,250</u> (18,750)	45,000 (15,000)	42,000 (14,000)
B	Unlimited	Unlimited	<u>324,000</u>	<u>216,000</u>	<u>135,000</u>	108,000	85,500
R-1, R-2 (w/ height increase)	Unlimited	Unlimited	<u>184,500</u> (61,500)	<u>123,000</u> (41,000)	<u>76,875</u> (25,625)	61,500 (20,500)	72,000 (24,000)


CBC Tall Wood – Sprinkler Increase Options

Example: R-2, Type IV-B Building




CBC Tall Wood – Podium Option (w/ Sprinkler Increase)

Example: R-2, Type IV-B Building
w/ area increase




w/ area increase + podium




CA Tall Wood – Sprinkler Increase Options

Example A-2, Type IV-C Building

w/sprinkler area increase



w/sprinkler height increase



CBC Tall Wood Opportunities – Large Area

	Construction Type (<u>Sprinklered Values</u>)						
	I-A	I-B	<u>IV-A</u>	<u>IV-B</u>	<u>IV-C</u>	IV-HT	III-A
Occupancies	Allowable Building Height above Grade Plane, Feet (CBC Table 504.3)						
B, F, M, S, U, R-3, R-4	Unlimited	180*	<u>270</u>	<u>180</u>	<u>85</u>	85	85
A, E, R-1, R-2 w/ area increase	Unlimited	160	<u>250</u>	<u>160</u>	<u>65</u>	65	65
	Allowable Number of Stories above Grade Plane (CBC Table 504.4)						
A-2, A-3, A-4 w/ area increase	Unlimited	11	<u>17</u>	<u>11</u>	<u>5</u>	3	3
B	Unlimited	12	<u>18</u>	<u>12</u>	<u>9</u>	6	6
R-1, R-2 w/ area increase	Unlimited	11	<u>17</u>	<u>11</u>	<u>7</u>	4	4
	Allowable Area Factor (At) for SM, Feet ² (CBC Table 506.2)						
A-1, A-2, A-3, A-4 w/o height increase	Unlimited	Unlimited	<u>135,000</u>	<u>90,000</u>	<u>56,250</u>	45,000	42,000
B	Unlimited	Unlimited	<u>324,000</u>	<u>216,000</u>	<u>135,000</u>	108,000	85,500
R-1, R-2 w/o height increase	Unlimited	Unlimited	<u>184,500</u>	<u>123,000</u>	<u>76,875</u>	61,500	72,000

CBC Tall Wood – Other Differences from IBC


OTHER NOTABLE DIFFERENCES:

- Section 403.3.2: The CBC requires all buildings taller than 120 ft to have dual water supply. The IBC requires it for buildings taller than 420 ft, or tall wood buildings more than 120 ft (end result is the same for tall wood).
- Table 504.3: H-1, H-2, H-3 & H-5 occupancies in the CBC allows 85 ft for IV-C; the IBC only allows 65 ft.
- Tables 504.3, 504.4 & 506.2: I occupancies, various differences in allowable heights & areas.
- Table 504.4: R-4 occupancies in the CBC only allows 11/5/5 stories for IV-A/IV-B/IV-C; the IBC allows 18/12/5.



Source: Michael Maltzan Architecture

MT Fire Resistance Ratings (FRR)




Section 722.7

The fire resistance rating of the mass timber elements shall consist of the fire resistance of the unprotected element (MT) added to the protection time of the noncombustible (NC) protection.



= FRR

MT Fire Resistance Ratings (FRR)



However, FRR doesn't always need to be from a combination of MT + NC. In some cases, just NC can be used, in other cases, just MT can be used:

Section 602.4

Mass timber elements shall meet the fire resistance rating requirements of this section based on either the fire resistance rating of the noncombustible protection, the mass timber, or a combination of both.

MT



NC



Noncombustible Protection (NC)

TABLE 722.7.1(a)

PROTECTION REQUIRED FROM NONCOMBUSTIBLE COVERING MATERIAL

<u>Required Fire Resistance Rating of Building Element per Tables 601 and 602 (hours)</u>	<u>Minimum Protection Required from Noncombustible Protection (minutes)</u>	
<u>1</u>	<u>40</u>	1 layer 5/8 Type X
<u>2</u>	<u>80</u>	2 layers 5/8 Type X
<u>3 or more</u>	<u>120</u>	3 layers 5/8 Type X

TABLE 722.7.1(b)

PROTECTION PROVIDED BY NONCOMBUSTIBLE COVERING MATERIAL

<u>Noncombustible Protection</u>	<u>Protection Contribution (minutes)</u>
<u>1/2 inch Type X Gypsum Board</u>	<u>25</u>
<u>5/8 inch Type X Gypsum Board</u>	<u>40</u>

MT Type IV Minimum Sizes

In addition to meeting FRR, all MT elements must also meet minimum sizes

These minimum sizes have been in place for the old Type IV construction (now called Type IV-HT) and the same minimum sizes also apply to MT used in the new Types IV-A, IV-B and IV-C construction.

Contained in Section 2304.11.



Photo:: Ema Peter

Type IV Minimum Sizes - Framing

Framing		Solid Sawn (nominal)	Glulam (actual)	SCL (actual)
Floor	Columns	8 x 8	6 ³ / ₄ x 8 ¹ / ₄	7 x 7 ¹ / ₂
	Beams	6 x 10	5 x 10 ¹ / ₂	5 ¹ / ₄ x 9 ¹ / ₂
Roof	Columns	6 x 8	5 x 8 ¹ / ₄	5 ¹ / ₄ x 7 ¹ / ₂
	Beams*	4 x 6	3 X 6 ⁷ / ₈	3 ¹ / ₂ X 5 ¹ / ₂

Minimum Width by Depth in Inches
See Section 2304.11 for details

*3" nominal width allowed where sprinklered



Photo: WoodWorks

Type IV Minimum Sizes – Floor/Roof Panels

Floor Panels/Decking:

- 4" thick CLT (actual thickness)
- 4" NLT/DLT/GLT (nominal thickness)
- 3" decking (nominal thickness) covered with: 1" decking or 15/32" WSP or 1/2" particleboard

Roof Panels/Decking:

- 3" thick CLT (actual thickness)
- 3" NLT/DLT/GLT (nominal thickness)
- 2" decking (nominal thickness)
- 1-1/8" WSP



MT Type IV Minimum Sizes – Walls

Exterior Walls for Type IV-A, B or C

- CLT or Non-combustible

Exterior Walls for Type IV-HT

- CLT or light-frame FRTW or Non-combustible
- 4" thick CLT (if CLT)
- 6" thick wall (if light-frame FRTW)




MT Fire Resistance Ratings (FRR)

How do you determine FRR of MT?

Two options:

1. Calculations in accordance with Section 722 → NDS Chapter 16
2. Tests in accordance with ASTM E119



MT Fire Resistance Ratings (FRR)

MT FRR Calculation Method:

- Section 703.3 allows several methods of determining FRR; one is calculations per Section 722
- Section 722.1 refers to NDS Chapter 16 for exposed wood FRR

703.3 Methods for determining fire resistance. The application of any of the methods listed in this section shall be based on the fire exposure and acceptance criteria specified in ASTM E119 or UL 263. The required *fire resistance* of a building element, component or assembly shall be permitted to be established by any of the following methods or procedures:

3. Calculations in accordance with Section 722.

722.1 General. The provisions of this section contain procedures by which the *fire resistance* of specific materials or combinations of materials is established by calculations. These procedures apply only to the information contained in this section and shall not be otherwise used. The calculated *fire resistance* of concrete, concrete masonry and clay masonry assemblies shall be permitted in accordance with ACI 216.1/TMS 0216. The calculated *fire resistance* of steel assemblies shall be permitted in accordance with Chapter 5 of ASCE 29. The calculated *fire resistance* of exposed wood members and wood decking shall be permitted in accordance with Chapter 16 of ANSI/AF&PA National Design Specification for Wood Construction (NDS).

MT Fire Resistance Ratings (FRR)

Nominal char rate of 1.5"/HR is recognized in NDS Chapter 16. Effective char depth calculated to account for duration of fire and structural reduction in heat-affected zone. AWC's TR 10 is a great resource for explanations and design examples of NDS Chapter 16 char calculations.





Table 16.2.1B Effective Char Depths (for CLT with $\beta_n=1.5\text{in./hr.}$)

Required Fire Endurance (hr.)	Effective Char Depths, a_{char} (in.)								
	lamination thicknesses, h_{lam} (in.)								
	5/8	3/4	7/8	1	1-1/4	1-3/8	1-1/2	1-3/4	2
1-Hour	2.2	2.2	2.1	2.0	2.0	1.9	1.8	1.8	1.8
1½-Hour	3.4	3.2	3.1	3.0	2.9	2.8	2.8	2.8	2.6
2-Hour	4.4	4.3	4.1	4.0	3.9	3.8	3.6	3.6	3.6

MT Fire Resistance Ratings (FRR)

Tested Assemblies Method:

- Many successful Mass Timber ASTM E119 fire tests have been completed by industry & manufacturers



Contact WoodWorks for Inventory of Tests

MT Fire Resistance Ratings (FRR)



Fire-Resistive Design of Mass Timber Members

Code Applications, Construction Types and Fire Ratings

Richard McCarty, P.E., S.E. • Senior Technical Director • WoodWorks
Scott Beneman, P.E., P.E. S.E. • Senior Technical Director • WoodWorks

For many years, exposed heavy timber framing elements have been permitted in U.S. buildings due to their inherent fire-resistance properties. The predictability of wood's char rate has been well-established for decades and has long been recognized in building codes and standards.

Today, one of the exciting trends in building design is the growing use of mass timber—i.e., large solid wood panel products such as cross-laminated timber (CLT) and nail-laminated timber (NLT)—for floor, wall and roof construction. Like heavy timber, mass timber products have inherent fire resistance that allows them to be left exposed and still achieve a fire-resistance rating. Because of their strength and dimensional stability, these products also offer a low-carbon alternative to steel, concrete, and masonry for many applications. It is this combination of exposed structure and strength that developers and designers across the country

are leveraging to create innovative designs with a warm yet modern aesthetic, often for projects that go beyond traditional norms of wood design.

This paper has been written to support architects and engineers exploring the use of mass timber for commercial and multi-family construction. It focuses on how to meet fire-resistance requirements in the International Building Code (IBC), including calculation and testing-based methods. Unless otherwise noted, references refer to the 2018 IBC.

Mass Timber & Construction Type

Before demonstrating fire-resistance ratings of exposed mass timber elements, it's important to understand under what circumstances the code currently allows the use of mass timber in commercial and multi-family construction.

A building's assigned construction type is the main indicator of where and when all wood systems can be used. IBC Section 602 defines five main options (Type I through V) with all but Type IV having subcategories A and B. Types III and V permit the use of wood framing throughout much of the structure and both are used extensively for modern mass timber buildings.

Type III (IBC 602.3) – Timber elements can be used in floors, roofs and interior walls. Fire-retardant-treated wood (FRTTW) framing is permitted in exterior walls with a fire-resistance rating of 2 hours or less.

Type V (IBC 602.5) – Timber elements can be used throughout the structure, including floors, roofs and both interior and exterior walls.

Type IV (IBC 602.4) – Commonly referred to as "heavy timber" construction, this option



Cartersville | Portland, Oregon
Kaiser Group | Pelt Architectural
Munro Structural Engineering

- ## Mass Timber Fire Design Resource
- Code compliance options for demonstrating FRR
 - Free download at woodworks.org



IV-A

Type IV-A Protection vs. Exposed



18 STORIES
BUILDING HEIGHT 270'
ALLOWABLE BUILDING AREA 972,000 SF
AVERAGE AREA PER STORY 54,000SF

TYPE IV-A



100% NC protection on all surfaces of Mass Timber

Credit: Susan Jones, atelierjones

Credit: Acton Ostry Architects, Fast + Epp

Type IV-A Fire Resistance Ratings (FRR)

IV-A



Primary Frame FRR

**3 HR (2 HR at
Roof)**

**Min. NC
Protection
120 min (80 min
at Roof)**

Ext or Int Bearing Wall FRR

3 HR

120 min

Floor Construction FRR

2 HR

80 min

Roof Construction FRR


1.5 HR

80 min



Credit: Urban One

Type IV-A Protection



Floor Surface Protection

Roof Construction Protection

Ext Wall Protection

Min. 1 inch of NC protection

**Min. 2 layers 5/8" type X gyp
on inside face**

**Min. 1 layer 5/8" type X gyp
on outside face**

**Min. 2 layers 5/8" type X gyp
on inside face (non-brg)**

**Min. 3 layers 5/8" type X gyp
on inside face (brg)**




Credit: Maxxon

Type IV-A Fire Resistance Ratings (FRR)

IV-A


Floor Panel Example (2 HR):



Type IV-A Fire Resistance Ratings (FRR)

IV-A

Primary Frame (3 HR) + Floor Panel Example (2 HR):



Type IV-B Protection vs. Exposed

IV-B



12 STORIES
BUILDING HEIGHT 180 FT
ALLOWABLE BUILDING AREA 648,000 SF
AVERAGE AREA PER STORY 54,000SF

TYPE IV-B

Credit: Susan Jones, atelierjones




Credit: Kaiser+Path

NC protection on all surfaces of Mass Timber except limited exposed areas

≈20% of ceiling or ≈40% of wall can be exposed, see code for requirements

Type IV-B Fire Resistance Ratings (FRR)



Primary Frame FRR

Ext or Int Bearing Wall FRR

Floor Construction FRR

Roof Construction FRR


FRR	Min. NC Protection
2 HR (1 HR at Roof)	80 min* (40 min* at Roof)
2 HR	80 min*
2 HR	80 min*
1 HR	40 min*

***Applicable to most locations; limited exposed MT permitted**



Credit: Urban One

Type IV-B Protection



IV-B

Floor Surface Protection

Roof Construction Protection

Ext Wall Protection

Min. 1 inch of NC protection

**Min. 1 layer 5/8" type X gyp
on inside face***

**Min. 1 layer 5/8" type X gyp
on outside face
Min. 2 layers 5/8" type X gyp
on inside face***

***Applicable to most locations; limited exposed MT permitted**




Credit: Maxxon

Type IV-B Fire Resistance Ratings (FRR)

IV-B

Floor Panel Example (2 HR):




***Applicable to most locations; limited exposed MT permitted**

Type IV-B Fire Resistance Ratings (FRR)

IV-B

Primary Frame (2 HR) + Floor Panel Example (2 HR):

*Applicable to most locations; limited exposed MT permitted



Type IV-B Protection vs. Exposed

IV-B

Limited Exposed MT allowed in Type IV-B for:

- **MT columns which are not an integral part of walls, no area limitation applies**
- **MT ceilings/beams up to 20% of floor area in dwelling unit or fire area, or**
- **MT walls/columns up to 40% of floor area in dwelling unit or fire area, or**
- **Combination of ceilings/beams and walls/columns, calculated as follows:**



Credit: Kaiser+Path

Type IV-B Protection vs. Exposed

IV-B

Mixed unprotected areas, exposing both ceilings and walls:

- In each dwelling unit or fire area, max. unprotected area =

$$(U_{tc}/U_{ac}) + (U_{tw}/U_{aw}) \leq 1.0$$

- U_{tc} = Total unprotected MT ceiling areas
- U_{ac} = Allowable unprotected MT ceiling areas
- U_{tw} = Total unprotected MT wall areas
- U_{aw} = Allowable unprotected MT wall areas



Credit: Kaiser+Path

Type IV-B Protection vs. Exposed

IV-B

Design Example: Mixing unprotected MT walls & ceilings



800 SF dwelling unit

- $U_{ac} = (800 \text{ SF}) * (0.20) = 160 \text{ SF}$
- $U_{aw} = (800 \text{ SF}) * (0.40) = 320 \text{ SF}$
- Could expose 160 SF of MT ceiling, OR 320 SF of MT walls, OR
- If desire to expose 100 SF of MT ceiling in Living room, determine max. area of MT walls that can be exposed

Type IV-B Protection vs. Exposed

IV-B

Design Example: Mixing unprotected MT walls & ceilings



$$(U_{tc}/U_{ac}) + (U_{tw}/U_{aw}) \leq 1.0$$

$$(100/160) + (U_{tw}/320) \leq 1.0$$

$$U_{tw} = 120 \text{ SF}$$

- Can expose 120 SF of MT walls in dwelling unit in combination with exposing 100 SF of MT ceiling

Type IV-B Protection vs. Exposed

IV-B

Horizontal separation of unprotected areas:

- Unprotected portions of mass timber walls and ceilings shall be not less than 15 feet from unprotected portions of other walls and ceilings, measured horizontally along the ceiling and from other unprotected portions of walls measured horizontally along the floor.



Credit: Kaiser+Path

IV-C

Type IV-C Protection vs. Exposed



9 STORIES
BUILDING HEIGHT 85'
ALLOWABLE BUILDING AREA 405,000 SF
AVERAGE AREA PER STORY 45,000 SF

TYPE IV-C

Credit: Susan Jones, atelierjones



Credit: Kaiser+Path, Ema Peter

All Mass Timber surfaces may be exposed

Exceptions: Shafts, concealed spaces, outside face of exterior walls

Type IV-C Fire Resistance Ratings (FRR)

IV-C



Primary Frame FRR

2 HR (1 HR at Roof)

Ext or Int Bearing Wall FRR

2 HR

Floor Construction FRR

2 HR



Roof Construction FRR

1 HR



Credit: Ema Peter

Type IV-C Protection



Floor Surface Protection

Roof Construction Protection

Ext Wall Protection

None req.'d

None req.'d

**Min. 1 layer 5/8" type X gyp
on outside face
None req.'d on inside face**




Credit: Maxxon

Type IV-C Fire Resistance Ratings (FRR)

IV-C

Floor Panel Example (2 HR):

No NC req.'d



Mass Timber Floor Panel


2 HR of MT FRR

No NC req.'d

Type IV-C Fire Resistance Ratings (FRR)


IV-C

Primary Frame (2 HR) + Floor Panel Example (2 HR):




Concealed Spaces in previous Type IV


Previous Type IV (now IV-HT) provisions prohibited concealed spaces




PERMITTED INSTALLATION



PROHIBITED INSTALLATION



PROHIBITED INSTALLATION



PROHIBITED INSTALLATION


Concealed Spaces in Type IV-HT

Type IV-HT will now permit concealed spaces where one of the following conditions exists:

1. The building is sprinklered throughout with an NFPA 13 sprinkler system and sprinklers are provided in the concealed space.
2. The concealed space is completely filled with noncombustible insulation.
3. Surfaces within the concealed space are fully sheathed with not less than 5/8" Type X gypsum.


Concealed spaces within interior walls and partitions with a one hour or greater fire resistance rating complying with Section 2304.11.2.2 do not require additional protection.

Concealed Spaces in Type IV-HT




Option 1

Sprinklers in
concealed spaces



Option 2

Noncombustible
insulation



Option 3

5/8" Type X gypsum
on all MT surfaces

Concealed Spaces in Type IV-A, IV-B & IV-C

New Type IV-HT concealed space provisions do not apply to Type IV-A, IV-B & IV-C;

But, can still have concealed spaces in Type IV-A, IV-B & IV-C:

- **Type IV-A & IV-B:** Combustible construction forming concealed spaces protected with NC of 80 minutes (2 layers of 5/8" Type X Gypsum)
- **Type IV-C:** Combustible construction forming concealed spaces protected with NC of 40 minutes (1 layer of 5/8" Type X Gypsum)



Photo: Ema Peter Photography




Image: ZGF Architects

Concealed Spaces in Type IV-A & IV-B




*Applicable to most locations; limited exposed MT permitted in IV-B

2 layers 5/8" type X gypsum*


w/o dropped ceiling

2 layers 5/8" type X gypsum

w/ dropped ceiling



Concealed Spaces in Type IV-C



Shaft Enclosures in Type IV-A, IV-B & IV-C



Exit & Hoistway Enclosures

E&H Enclosures FRR

<p>Up to 12 Stories or 180 ft: MT protected with 2 layers 5/8" type X gyp (if 2 HR req'd) or 3 layers 5/8" type X gyp (if 3 HR req'd) both sides</p> <p>Above 12 Stories or 180 ft: Noncombustible shafts (Section 602.4)</p>	<p>NC or MT protected with 2 layers 5/8" type X gyp (Section 602.4.2.6) both sides</p>	<p>NC or MT protected with 1 layer 5/8" type X gyp (Section 602.4.3.6) both sides</p>
<p>2 HR (not less than FRR of floor assembly penetrated, Section 713.4)</p>		

Mid-Rise vs. High-Rise




FIGURE 6-6 Determination of high-rise building

CLT Fire Performance – Fire Re-Growth

In tall buildings, preventing fire re-growth is key. Fire re-growth is a phenomenon in which the heat-release rate of a fire intensifies following a decay phase. Fire re-growth can be initiated when delamination occurs (char fall-off), as this exposes un-charred wood surfaces, thereby resulting in an influx of fuel available for consumption by the fire.



Photo: Urban One



Photo: ARUP

CLT Fire Performance – Char Fall-Off

Facts about CLT char fall-off:

- Only an item to consider in tall buildings. Important to avoid in high-rise construction where required performance is containment of fire within compartment of origin with no sprinkler or fire service suppression
- Not applicable when discussing mid-rise mass timber (or any building under types II, III, IV-HT or V)
- Largely a function of adhesive performance under high temps
- Has been addressed in PRG 320-18 (required for all CLT, not just tall wood)



Photo: FPInnovations


CLT Fire Performance – PRG 320

Section 602.4 added:

Cross-laminated timber shall be labeled as conforming to PRG 320-18 as referenced in Section 2303.1.4.



Photo: ARUP



Connection Fire Protection

In Construction Types IV-A, IV-B & IV-C, building elements are required to be FRR as specified in Tables 601 and 602. Connections between these building elements must be able to maintain FRR no less than that required of the connected members.

16.3 Wood Connections

Wood connections, including connectors, fasteners, and portions of wood members included in the connection design, shall be protected from fire exposure for the required fire resistance time. Protection shall be provided by wood, fire-rated gypsum board, other approved materials, or a combination thereof.

Source: NDS



Photo: MyTiCon

Connection Fire Protection

Many ways to demonstrate connection fire protection: calculations, prescriptive NC, test results, others as approved by AHJ



Photo: John Stamets



Photo: Josh Partee



Photo: Christian Columbres



Photo: Blaine Brownell

Connection Fire Protection

**2017 Glulam Beam to Column Connection
Fire Tests under standard ASTM E119
time-temperature exposure**



Photo: ARUP/SLB



Connection Fire Protection

Softwood Lumber Board **Glulam Connection Fire Test** Summary Report

Issue | June 5, 2017

SOUTHWEST RESEARCH INSTITUTE®

5020 CULEBRA ROAD • 78238-5166 • P.O. DRAWER 28510 • 78228-0510 • SAN ANTONIO, TEXAS, USA • (210) 864-5111 • WWW.SWRI.ORG

CHEMISTRY AND CHEMICAL ENGINEERING DIVISION

FIRE TECHNOLOGY DEPARTMENT
WWW.FIRE.SWRI.ORG
FAX (210) 523-3377



**FIRE PERFORMANCE EVALUATION OF A LOAD BEARING
GLULAM BEAM TO COLUMN CONNECTION, INCLUDING A
CLT PANEL, TESTED IN GENERAL ACCORDANCE WITH
ASTM E119-16a, STANDARD TEST METHODS FOR FIRE TESTS
OF BUILDING CONSTRUCTION AND MATERIALS**

FINAL REPORT
Consisting of 32 Pages

Full Report Available at:

<https://www.thinkwood.com/wp-content/uploads/2018/01/reThink-Wood-Arup-SLB-Connection-Fire-Testing-Summary-web.pdf>



Penetration Fire Protection

Although not a new code requirement or specific to tall wood, more testing & information is becoming available on firestopping of penetrations through MT assemblies



Penetration Fire Protection

Most firestopping systems include combination of fire safing (e.g. noncombustible materials such as mineral wool insulation) plus fire caulk



Penetration Fire Protection

**Firestop systems tests on Mass Timber:
Contact WoodWorks for information**

SOUTHWEST RESEARCH INSTITUTE®

8225 CULBERT ROAD 18736-1188 • P.O. DRAWER 28810 78228-0510 • SAN ANTONIO, TEXAS, USA • (210) 584-5111 • WWW.SWRI.ORG

CHEMISTRY AND CHEMICAL ENGINEERING DIVISION

FIRE TECHNOLOGY DEPARTMENT
WWW.FIRE.SWRI.ORG
FAX (210) 532-3277



FIRE RESISTANCE PERFORMANCE EVALUATION OF A PENETRATION FIRESTOP SYSTEM TESTED IN ACCORDANCE WITH ASTM E814-13A, STANDARD TEST METHOD FOR FIRE TESTS OF PENETRATION FIRESTOP SYSTEMS

FINAL REPORT
Consisting of 18 Pages

SwRI® Project No. 01.21428.01.001a
Test Date: September 30, 2015
Report Date: October 22, 2015

Prepared for:

American Wood Council
222 Catotlin Circle SE
Leesburg, VA 20175

FIRE PERFORMANCE OF FIRESTOPS, PENETRATIONS, AND FIRE DOORS IN MASS TIMBER ASSEMBLIES

Lindsay Ranger¹, Christian Dagenais¹, Conroy Lum¹, Tony Thomas¹

ABSTRACT: Integrity and continuity must be maintained for fire separations required to provide for prevent passage of hot gases or increased temperature on the unexposed side. Vulnerable locations, where are introduced into mass timber systems, are susceptible to fire spread. Service and closure penetrations in mass timber fire separation have been investigated. Many of the fire stop systems were able to achieve 1-1/2 hours of fire resistance, which would be required for 2-hr fire resistance rated assemblies, for tall wood buildings. Construction details are outlined which ensure adequate fire performance of these penetrations.

KEYWORDS: Firestop, through-penetrations, fire rated door, mass timber, cross-laminated timber buildings, fire resistance

1 INTRODUCTION

Many tall wood buildings using mass timber are planned or are currently being designed for construction around the world. A few have been built in Canada, including an 18 storey cross-laminated timber (CLT) and glulam building in British Columbia. The prescriptive requirements in the National Building Code of Canada (NBCC) [1] do not (yet) permit the construction of wood buildings taller than six stories, however an alternative

construction, as well as in several other building designs.

Although the general fire performance of mass timber is well documented, there are still several areas that warrant further investigation to ensure that safety levels are met and a number of design options are available for designers to use. Generating generic assemblies will reduce the need for testing completed on an individual construction



409 DUNDAS STREET, SUITE 900
VANCOUVER, BC V6C 1T2 CANADA
P 604 681 4400
F 604 681 4410
www.ghl.ca
Members of ASCE, Engineers of Ontario

FIRESTOPPING TEST WITNESS REPORT


for

NORDIC STRUCTURES

Sealants at MT Panel Edges

Section 703.9 Sealing of adjacent mass timber elements. In buildings of Type IV-A, IV-B and IV-C construction, sealant or adhesive shall be provided to resist the passage of air in the following locations:

1. At abutting edges and intersections of mass timber building elements required to be fire resistance-rated
2. At abutting intersections of mass timber building elements and building elements of other materials where both are required to be fire resistance-rated.



Sealants at MT Panel Edges

Sealants shall meet the requirements of ASTM C920 (elastomeric joint sealants). Adhesives shall meet the requirements of ASTM D3498 (gap filling construction adhesives, i.e. not fire caulk).

Exception: Sealants or adhesives need not be provided where they are not a required component of a fire resistance- rated assembly.



Sealants at MT Panel Edges

Several MT fire tested assemblies have successfully been completed w/o adhesives/sealants at abutting panel edges

Periodic special inspections of adhesive/sealant installation will be required (when required to be installed)



QUESTIONS?

Janelle Leafblad, PE

Regional Director | OR, WA, AK, HI, ID
janelle.leafblad@woodworks.org

Chelsea Drenick, SE

Regional Director | N.CA, NV, UT
chelsea.drenick@woodworks.org

This concludes The American Institute
of Architects Continuing Education
Systems Course





Copyright Materials

This presentation is protected by US
and International Copyright laws.
Reproduction, distribution, display and use of
the presentation without written permission
of the speaker is prohibited.

© The Wood Products Council 2020