

APA


Frame It Right!
Engineered Wood use in Big Buildings




Presented by Larry Oenning, PE
October 7, 2022

1

Introduction



APA Regional Representatives




Larry Oenning, P.E.
larry.oenning@apawood.org

APA

2

Who is APA – The Engineered Wood Association?

APA represents approximately 175 member mills in 23 states and seven provinces.



- Quality Services
- Technical Services
- Field Services
- Marketing Communications

- ☐ Voice of industry
- ☐ Mark of quality
- ☐ Technical support
- ☐ Free education
- ☐ Research
- ☐ Non-profit Trade Assoc.
- ☐ HQ in Tacoma, WA
- ☐ www.apawood.org


The leading resource for information about engineered wood products.

APA

4

Agenda

- Why is training needed?
- Building from the ground up
 - Woods Strength
 - Walls
 - Floors
 - Roofs
 - Special topics
- Q&A



5

Engineered Wood Products (EWP)



- ✓ Plywood
- ✓ OSB – Oriented Strand Board
- ✓ I-joists
- ✓ Glulams – Glued Laminated Lumber
- ✓ LVL – Laminated Veneer Lumber
- ✓ LSL – Laminated Strand Lumber
- ✓ OSL – Oriented Strand Lumber
- ✓ CLT – Cross Laminated Timber




6

6


Wood as a Building Material

Wood has a strong and weak direction


Load parallel to grain



Stronger



Load perpendicular to grain




Weaker



7

Wood's Strength Direction




Plywood

8


Wood's Strength Direction

OSB flakes are engineered for strength.


OSB Mat




9




10



11



12



14

APA Stamp in the Field




15

Walls

Wall Sheathing


- Racking/shear resistance
- Square
- Wind pressure resistance
- Nonstructural benefits
- Installation:
 - Per engineer's design
 - Min. fastening: 8d nails @ 6" o.c. perimeter and 12" o.c. in the field min.



19

Walls


- Wall sheathing
 - Plywood or OSB
 - Orientation
 - 8' to 10' panels



20

Lateral Forces


Modes of Failure



22

Anchor Bolts

- Size and spacing per engineer
- Large plate washers (3"x3"x0.229") prevent cross grain bending-splitting of sill plate (Required in Seismic Zones D and E, IBC 2308.3.1) APA recommends for High Wind Applications



23

Walls

Hold-down hardware



24

Shear Wall Design




Special Design Provisions for Wind & Seismic (SDPWS), provides designers three acceptable methods for designing wood shear walls to resist lateral forces.

APA

28

Segmented Shear Walls




29

Perforated Shear Walls



Continuously sheathed walls




30

Force Transfer Around Openings (FTAO) Shear Walls



Continuously sheathed walls



31

FTAO



Force Transfer Around Openings

- Window Flange
- Length of strap
- Blocking in interior - flatwise
- Strap interior/exterior
- APA FTAO Calculator
- APA T555 - FTAO Publication




32

Structural I Panels

- Increased shear capacity
- Increased stiffness, especially across the panel
- Plywood & available in OSB (performance tested)
- Before specifying, check local availability




Group 1 Species



34

Staggered Fastening



35


Floors



37

Floors

- IBC Minimum Nailing
 - Panel ends - 6" on center
 - Intermediate - 12" on center
 - Fastener edge distance - 3/8 inch




38

"Composite action"




Q300 - Builder Tips:
Construct a Solid, Squeak-Free Floor System



39

Fully Fasten with Clamping Force




40

Floors

Sturd-I-Floor

- Combined subfloor & underlayment
- Resistant to concentrated & impact loads
- Plywood or OSB



41

Overdriven Fasteners

Nail installation

- Overdriving reduces performance
- APA recommends – add one for every two overdriven



Resource: Effect of Overdriven Fasteners on Shear Capacity publication TT-012

42

Overdriven Nails

Refer to APA publication TT-012
To Maintain Shear Capacity:


Overdriven Fasteners	Overdriven Distance	Action
≤ 20% Perimeter	< 1/8"	None
> 20% Perimeter	> 1/16"	Add 1 nail for every 2 overdriven
Any	> 1/8"	



43

Floor Joist Layout - Consistency Counts

Inconsistent spacing & span




APA

44

Use Wood's Strength Direction

I-joist

- Used for floor & roof framing
- Long lengths available




46

Sustainability

I-Joist vs. Lumber

- Both at 16" o.c.
 - 36% less wood fiber
- I-Joist at 19.2" o.c. & Lumber at 16" o.c.
 - 46% less wood fiber



I-Joist

VS.




Lumber

47


Cutting Holes in I-Joists

Before cutting any holes, refer to the I-joist manufacturer's guidelines.



48

48




50



51



52




55

Structural Composite Lumber

Laminated Veneer Lumber (LVL)

- Veneers bonded together
- Common uses
 - Beams
 - Headers
 - Rafters
 - Scaffold planking




56

56

Floors

Field notching and drilling LVL (Form G535)

Minimum amount of spacing = 2 x diameter of the largest hole




Zone where holes are permitted for passage of wires, conduits, etc.

No holes greater than 2" in diameter. No more than 3 holes per span.

Check with the I-joist Manufacturer's guidelines for holes

57

G535 - Field notching and drilling LVL



58

Floors


Laminated Strand Lumber (LSL)




59




60



61



62



63

Floors

Field notching and drilling glulam (Form S560)

FIGURE 3
ZONES WHERE SMALL HORIZONTAL HOLES ARE PERMITTED IN A UNIFORMLY LOADED, SIMPLY SUPPORTED BEAM

Shear critical zone, Moment critical zone, Bearing critical zone. Zones where horizontal holes are permitted for passage of wires, conduit, etc.

64

Large Holes

Large Diameter Holes in LVL and Glulam Beams (Forms V900, V700)

TECHNICAL NOTE
Effect of Large Diameter Horizontal Holes on the Bending and Shear Properties of Laminated Veneer Lumber
Number V9008
February 2020

TECHNICAL NOTE
Effect of Large Diameter Horizontal Holes on the Bending and Shear Properties of Structural Glued Laminated Timber
Number V7008
February 2020

65

Season Checks in Glulams

Seasoning Checks

Uneven surfaces with torn wood fiber

APA Owners Guide to Understanding Checks in Glued Laminated Timber – Form F450

67

Wood Properties

Checking Evaluation

- Guidelines established for what size checks are okay without an engineering analysis
- Published in *Owner's Guide to Understanding Checks in Glued Laminated Timber*, APA Form F450

See APA Technical Note: Evaluation of Check Size in Glued Laminated Timber Beams, Form F475

IS MY GLULAM OK?

Is the span of the glulam beam greater than 10 times the depth?
Example: Depth = 12", span is greater than 120"

Where do the checks appear?

BOTTOM FACE
Is the check parallel to the grain of wood?
YES NO


SIDE FACE
Is the depth of the check less than one-third the width of the beam, and is the length less than one-third the length of the beam?
YES NO

END FACE
Is the length of the check or split less than one-half the depth of the member?
YES NO


NO STRUCTURAL CONCERN
If the checks on your building's glulam pose no structural problems, engineering analysis is not required. These recommendations apply to both simple span beams and multiple span beams under uniform loads.

CONSULT DESIGN PROFESSIONAL
If checks in glulam exceed these size and situation, a qualified design professional should evaluate the effect of the checks.


68




69




70




71




72




73



74



75



79



80


Narrow Width Roof Sheathing Form R275

Narrow Roof Sheathing

- If WSP* is 16" to 24"
 - 2 clips at lower edge acceptable
 - Lumber block lower edge
- If WSP is 12" to 16"
 - Lumber block lower edge
- If WSP is less than 12"
 - Lumber block upper and lower edges
(Regardless of adjacent ridge or valley)

*"WSP" = wood structural panel (plywood or OSB)

81



82

Special Topics

Special topics

- On-site moisture management
- Shrinkage

84

Special Topics



85

Prevent Moisture Intrusion Drying of Subfloor



Fans




Dehumidification

86

Special Topics


Installation Recommendations* Space all panels 1/8"



* Recommended spacing of floor underlayment panels = 1/32"

87

Proper spacing



88

Special Topics

What can happen if panels aren't allowed to acclimate?



93

Special Topics



94

Special Topics




Nailing
approx.
3" oc

95

Special Topics

Buckling - High Risk Applications:

- Panels installed parallel to supports (e.g. walls)
- Edge nailing 4" o.c. or closer
- Long lasting rainy weather or high humidity
- Panels installed within a few days of their manufacture
- Others...




High risk because the conditions may reduce edge gap's effectiveness in absorbing panel expansion.

96

Special Topics

Attic Spaces require adequate ventilation

- Provide adequate moisture control both during and after construction
- Ventilate attics and roof structural spaces per requirements of International Building Code (IBC) Section 1203.2



APA

99

APA Form F505 – Q & A



FAQs

Questions About Structural Plywood and OSB Performance

APA-trademarked panel performance concerns are infrequent, but they arise on occasion. Some permissible performance, grade, growth or natural characteristics are often interpreted as performance issues when they are merely cosmetic and have no impact on panel performance. A guide of terms associated with panel performance follows.

Questions include:

- Delamination
- Buckling
- Checking
- Warping
- Grade
- Swelling
- Flaking
- Applications
- Siding substrate

100

Special Topics

Panel Expansion of large structures

- Panel expansion may accumulate through the framing of large, continuous floor or roof decks
- Provide temporary expansion joints to minimize displacement when building plan dimension exceeds 80'



101

Special Topics

Provisions for large structures


12" gap in wall bottom plate at expansion joint 3/4" temporary expansion joint at 80' intervals



APA Technical note U425

102

Special Topics



Provisions for large structures

Roofs:

- Sheath 80-foot sections, omitting a roof sheathing panel between sections
- Complete installation with fill-in panels immediately before sheathing is covered with roof underlayment

103

Special Topics

Shrinkage occurs primarily in horizontal wood dimensional lumber members such as wall plates and floor joists.





104

Special Topics

Tangential shrinkage averages about twice that of radial shrinkage in most species.

Longitudinal shrinkage or expansion is negligible.




105

105

Special Topics

Zone of movement

- Shrinkage occurs primarily in horizontal members such as wall plates and floor joists.
- WoodWorks paper, *Accommodating Shrinkage in Multi-Story Wood-Frame Structures*



108

Quick Summary



Simple steps make a big difference:


- Follow the prints and specifications
- Space panels
- Follow fastening guidelines
- Check load paths/stacking
- Control moisture



Assistance is available from APA

110

APA Resources



APA Engineered Wood Construction Guide (E30)

- The “go to” APA publication
- Free download
- \$12 to buy hard copy
- www.apawood.org/publication



111

Thank You!



Larry Oenning, PE
larry.oenning@apawood.org
360.900.9992

APA Help Desk:
(253) 620-7400
help@apawood.org

www.apawood.org

114