

# New Tall Wood Code Provisions: Advanced Fire Design for Exposed Timber

Anthony Harvey, PE

Regional Director

NIR Center | Photo: Hennebery Eddy Architects | Architect: Hennebery Eddy Architects

#### Questions? Ask me anything.





Anthony Harvey, PE
Regional Director | OH, IN, KY, MI
513.222.3038

anthony.harvey@woodworks.org



"The Wood Products Council" is a Registered Provider with The American Institute of Architects Continuing Education Systems (AIA/CES), Provider #G516.

Credit(s) earned on completion of this course will be reported to AIA CES for AIA members. Certificates of Completion for both AIA members and non-AIA members are available upon request.

This course is registered with AIA CES for continuing professional education. As such, it does not include content that may be deemed or construed to be an approval or endorsement by the AIA of any material of construction or any method or manner of handling, using, distributing, or dealing in any material or product.

Questions related to specific materials, methods, and services will be addressed at the conclusion of this presentation.



#### Course Description

The 2021 International Building Code (IBC) includes a series of changes that significantly expand the opportunities for tall timber structures. Three new construction types—Type IV-A, IV-B and IV-C—will allow the use of mass timber or noncombustible materials in buildings up to 18 stories tall. These new types are based on the previous Heavy Timber construction type (renamed Type IV-HT) but with additional fire-resistance ratings and levels of required noncombustible protection. This presentation will take a detailed look at the new code provisions and methods of addressing requirements for fire resistance and exposed timber. Topics will include tall wood-specific high-rise and sprinkler requirements, methods of demonstrating fire-resistance ratings, fire design for penetrations, connections and abutting panels, allowances for exposed timber, exterior walls, concealed spaces, and more.

#### Learning Objectives

- 1. Explore the three new tall wood construction types and discuss related code provisions such as allowable heights and fire-resistance ratings.
- 2. Discuss code-compliant options for exposing mass timber, where up to 2-hour fire-resistance ratings are required, and demonstrate design methodologies for achieving these ratings.
- 3. Review timber exposure strategies for IV-B construction, emphasizing code compliance topics such as horizontal separation and exposure area limits.
- 4. Highlight resources available to designers for fire-resistance design in tall timber structures, emphasizing tested assemblies, allowances for concealed spaces and contributions of noncombustible protection layers.

#### **CONSTRUCTION TYPES REVEIW**



Since its debut, IBC has contained 9 Construction Type options 5 Main Types (I, II, III, IV, V) with all but Type IV having sub-types A and B


TYPE I		TYF	PE II	TYPE III		TYPE IV	TYP	PE V
Α	В	Α	В	Α	В	HT	A	В


## U.S. BUILDING CODES Tall Wood Ad Hoc Committee

# 2021 IBC Introduces 3 New Tall Wood Construction Types: IV-A, IV-B, IV-C, Previous Type IV is renamed Type IV-HT

BUILDING	TYPE	I	TYPE	II	TYPE	Ш	TYPE	IV			TYPE	V
ELEMENT	Α	В	Α	В	Α	В	Α	В	С	НТ	Α	В

#### **Tall Timber Construction Types**





#### BUSINESS OCCUPANCY [GROUP B]

\*BUILDING FLOOR-TO-FLOOR HEIGHTS ARE SHOWN AT 12'-0" FOR ALL EXAMPLES FOR CLARITY IN COMPARISON BETWEEN 2015 TO 2021 IBC CODES.

Credit: Susan Jones, atelierjones

## **Tall Wood Building Size Limits**

		Construction Type (All <u>Sprinklered Values</u> )							
	I-A	I-B	<u>IV-A</u>	<u>IV-B</u>	<u>IV-C</u>	IV-HT	III-A		
Occupancies	Allo	wable Build	ing Height a	bove Grade l	Plane, Feet (1	IBC Table 50	4.3)		
A, B, R	Unlimited	180	<u>270</u>	<u>180</u>	<u>85</u>	85	85		
	Allowable Number of Stories above Grade Plane (IBC Table 505.4)								
A-2, A-3, A-4	Unlimited	12	<u>18</u>	<u>12</u>	<u>6</u>	4	4		
В	Unlimited	12	<u>18</u>	<u>12</u>	9	6	6		
R-2	Unlimited	12	<u>18</u>	<u>12</u>	8	5	5		
		Allowable A	Area Factor (	(At) for SM,	Feet <sup>2</sup> (IBC 7	Table 506.2)			
A-2, A-3, A-4	Unlimited	Unlimited	135,000	90,000	<u>56,250</u>	45,000	42,000		
В	Unlimited	Unlimited	324,000	216,000	135,000	108,000	85,500		
R-2	Unlimited	Unlimited	184,500	123,000	76,875	61,500	72,000		

## **Tall Wood Building Size Limits**

	Construction Type ( <u>Unsprinklered Values</u> )						
	I-A	I-B	<u>IV-A</u>	<u>IV-B</u>	<u>IV-C</u>	IV-HT	
Occupancies	Allowa	ble Building H	Height above G	Frade Plane, F	eet (IBC Table	504.3)	
A, B, R	Unlimited	160	<u>65</u>	<u>65</u>	<u>65</u>	65	
	Allov	vable Number	of Stories abo	ve Grade Plan	e (IBC Table 5	505.4)	
A-2, A-3, A-4	Unlimited	11	<u>3</u>	3	3	3	
В	Unlimited	11	<u>5</u>	<u>5</u>	<u>5</u>	5	
R-2	Unlimited	11	4	4	4	4	
	A	llowable Area	Factor (At) for	r SM, Feet <sup>2</sup> (I	BC Table 506.	2)	
A-2, A-3, A-4	Unlimited	Unlimited	45,000	30,000	18,750	15,000	
В	Unlimited	Unlimited	108,000	72,000	45,000	36,000	
R-2	Unlimited	Unlimited	61,500	41,000	<u>25,625</u>	20,500	

Even so, Sprinklers may be required by 903.2 (all occupancies) and definitely for residential (420.4)

## **Tall Wood Building Size Limits**

	Construction Type ( <u>Unsprinklered Values</u> )						
	I-A	I-B	<u>IV-A</u>	<u>IV-B</u>	<u>IV-C</u>	IV-HT	
Occupancies	Allowa	ble Building I	Height above G	Frade Plane, F	eet (IBC Table	504.3)	
A, B, R	Unlimited	160	<u>65</u>	<u>65</u>	<u>65</u>	65	
	Allo	nialmo	ostra bo	cases	e (IBC Table 5	(05.4)	
A-2, A-3, A-4	Unlimited.		will be	<u>3</u>	$\mathbf{z} = \mathbf{z}^{3}$	3	
В	Unan Red	ikieis	wiii be	regun		5	
R-2	Unlimited	11	4	4	4	4	
	A	llowable Area	Factor (At) for	r SM, Feet <sup>2</sup> (I	BC Table 506.	2)	
A-2, A-3, A-4	Unlimited	Unlimited	45,000	30,000	18,750	15,000	
В	Unlimited	Unlimited	108,000	72,000	45,000	36,000	
R-2	Unlimited	Unlimited	61,500	41,000	25,625	20,500	

Even so, Sprinklers may be required by 903.2 (all occupancies) and definitely for residential (420.4)

## Non-Tall Opportunities – Large Area

		Construction Type (All <u>Sprinklered Values</u> )							
	I-A	I-B	<u>IV-A</u>	<u>IV-B</u>	<u>IV-C</u>	IV-HT	III-A		
Occupancies	Allo	wable Build	ing Height al	bove Grade l	Plane, Feet (l	BC Table 50	4.3)		
A, B, R	Unlimited	180	<u>270</u>	<u>180</u>	<u>85</u>	85	85		
	Allowable Number of Stories above Grade Plane (IBC Table 505.4)								
A-2, A-3, A- 4	Unlimited	12	<u>18</u>	<u>12</u>	<u>6</u>	4	4		
В	Unlimited	12	<u>18</u>	<u>12</u>	9	6	6		
R-2	Unlimited	12	18	12	8	5	5		
		Allowable A	Area Factor (	At) for SM,	Feet <sup>2</sup> (IBC 7	Table 506.2)			
A-2, A-3, A- 4	Unlimited	Unlimited	135,000	90,000	<u>56,250</u>	45,000	42,000		
В	Unlimited	Unlimited	324,000	216,000	135,000	108,000	85,500		
R-2	Unlimited	Unlimited	184,500	123,000	<u>76,875</u>	61,500	72,000		


### Type IV-A



18 STORIES
BUILDING HEIGHT 270'
ALLOWABLE BUILDING AREA 972,000 SF
AVERAGE AREA PER STORY 54,000 SF

#### TYPE IV-A

Credit: Susan Jones, atelierjones







Photos: Structurlam, naturally:wood,

Fast + Epp

#### **Type IV-A Height and Area Limits**



18 STORIES
BUILDING HEIGHT 270'
ALLOWABLE BUILDING AREA 972,000 S
AVERAGE AREA PER STORY 54,000SF

TYPE IV-A

Credit: Susan Jones, atelierjones

Occupancy	# of Stories	Height	Area per Story	Building Area
A-2	18	270 ft	135,000 SF	405,000 SF
В	18	270 ft	324,000 SF	972,000 SF
M	12	270 ft	184,500 SF	553,500 SF
R-2	18	270 ft	184,500 SF	553,500 SF

Areas exclude potential frontage increase

In most cases, Type IV-A height & story allowances = 1.5 \* Type I-B height & story allowances


Type IV-A area = 3 \* Type IV-HT area

18 STORIES
BUILDING HEIGHT 270'
ALLOWABLE BUILDING AREA 972,000 SF
AVERAGE AREA PER STORY 54,000SF

#### TYPE IV-A

Credit: Susan Jones, atelierjones

#### Type IV-A Protection vs. Exposed



100% NC protection on all surfaces of Mass Timber

## Type IV-A Fire Resistance Ratings (FRR)







Primary Frame FRR

Ext or Int Bearing Wall FRR

Floor Construction FRR

**Roof Construction FRR** 

3 HR (2 HR at Roof)

3 HR

2 HR

1.5 HR



## Type IV-A Fire Resistance Ratings (FRR)







Primary Frame FRR

Ext or Int Bearing Wall FRR

Floor Construction FRR

**Roof Construction FRR** 

1/2" Type X Gypsum = 25 min

FRR	Min. NC Protection
3 HR (2 HR at	120 min (80 min
Roof)	at Roof)
3 HR	120 min
2 HR	80 min
1.5 HR	80 min

5/8" Type X Gypsum = 40 min



## Noncombustible Protection (NC)

## Where timber is required to be protected, NC must contribute at least 2/3 FRR


#### Required Noncombustible Contribution to FRR

FRR of Building Element (hours)	Minimum from Noncombustible Protection (minutes)
1	40
2	80
3 or more	120

Source: 2021 IBC Section 722.7

## Noncombustible Protection (NC)





The definition of "Noncombustible Protection (For Mass Timber)" is created to address the passive fire protection of mass

timber.

Mass timber is permitted to have its <u>own</u> fire-resistance rating (e.g., Mass Timber only) or have a fire resistance rating based on the fire resistance through a <u>combination</u> of the mass timber fire-resistance plus protection by non-combustible materials as defined in Section 703.5 (e.g., additional materials that delay the combustion of mass timber, such as gypsum board).



## Noncombustible Protection (NC)

#### **Prescriptive Noncombustible Contributions to FRR**

Type of Protection	Contribution per Layer (minutes)
1/2" Type X gypsum board	25
5/8" Type X gypsum board	40

Source: 2021 IBC Section 722.7.1

#### **Required Noncombustible Contribution to FRR**

FRR of Building Element (hours)	Minimum from Noncombustible Protection (minutes)
1	40
2	80
3 or more	120


1 layer 5/8 Type X

2 layers 5/8 Type X

3 layers 5/8 Type X

Source: 2021 IBC Section 722.7





**IBC 722.7** 

The fire resistance rating of the mass timber elements shall consist of the fire resistance of the unprotected element (MT) added to the protection time of the noncombustible (NC) protection.














However, FRR Doesn't always need to be from a combination of MT + NC. In some cases, just NC can be used, in other cases, just MT can be used:



**IBC 602.4** 

Mass timber elements shall meet the fire resistance rating requirements of this section based on <u>either</u> the fire resistance rating of the noncombustible protection, the mass timber, <u>or</u> a combination of both.




#### MT Type IV Minimum Sizes

In addition to meeting FRR, all MT elements must also meet minimum sizes

These minimum sizes have been in place for old type IV (current type IV-HT) construction and the same minimums sizes also apply to MT used in new types IV-A, IV-B and IV-C

Contained in 2021 IBC 2304.11 (2015 IBC Chap 6)




## **Type IV Minimum Sizes - Framing**

F	raming	Solid Sawn (nominal)	Glulam (actual)	SCL (actual)
or	Columns	8 x 8	$6^3/_4 \times 8\%$	7 x 7½
Floor	Beams	6 x 10	5 x 10½	5¼ x 9½
of	Columns	6 x 8	5 x 8¼	5¼ x 7½
Roof	Beams*	4 x 6	$3 \times 6^7/_8$	3½ X 5½

Minimum Width by Depth in Inches
See IBC 2018 2304.11 or IBC 2015 602.4 for Details

\*3" nominal width allowed where sprinklered



### Type IV Minimum Sizes – Floor/Roof Panels

#### **Floor Panels/Decking:**

- 4" thick CLT (actual thickness)
- 4" NLT/DLT/GLT (nominal thickness)
- 3" thick (nominal) decking covered with:
   1" decking or 15/32" WSP or ½"
   particleboard

#### **Roof Panels/Decking:**

- 3" thick CLT (nominal thickness)
- 3" NLT/DLT/GLT (nominal thickness)
- 2" decking (nominal thickness)
- 1-1/8" WSP







#### MT Type IV Minimum Sizes – Walls

#### **Exterior Walls for Type IV-A B C**

CLT or Non-combustible

#### **Exterior Walls for Type IV-HT**

- CLT or FRTW or Non-combustible
- IBC 2018 6" Thick Wall (FTW or CLT)
- IBC 2021 4" Thick <u>CLT</u>





### MT Type IV Minimum Sizes – Walls

#### **MT Interior Walls in all Type IV:**

- Laminated construction 4" thick
- Solid wood construction min. 2 layers of 1" matched boards

#### Other Interior Walls in Type IV A,B,C

- Non-combustible (0 hr for nonbearing)
- **Other Interior Walls in Type IV HT**
- Non-combustible (1 hr min)
- Wood stud wall (1 hr min)

Verify other code requirements for FRR (eg. interior bearing wall; occupancy separation)





## Type IV-A Fire Resistance Ratings (FRR)

IV-A

#### FRR Examples:

Primary Structural Frame (Beam, Column, Bearing Wall):

**3 HR Required** 

NC protection = at least 120 min

Use 3 layers of 5/8" type X Gypsum = 120 min (2 HR)
 Mass Timber FRR req'd = 3 HR - 2 HR = 1 HR





## Type IV-A Fire Resistance Ratings (FRR)

#### IV-A

#### FRR Examples:

#### **Floor Panels:**

**2 HR Required** 

NC Protection = at least 80 min

- Use 2 layers of 5/8" type X Gypsum = 80 min (1.33 HR),
   plus:
  - Mass Timber FRR req'd = 2 HR 1.33 HR = 40 min,
     or
- Use 3 layers of 5/8" Type X Gypsum = 120 min (2 HR) and no FRR from MT req'd





#### **Type IV-A Protection**







Floor Surface Protection

**Roof Construction Protection** 

**Ext Wall Protection** 

Min. 1 inch of NC protection

Min. 2 layers 5/8" type X gyp on inside face

Min. 1 layer 5/8" type X gyp on outside face


Min. 2 layers 5/8" type X gyp on inside face (non-brng) Min. 3 layers 5/8" type X gyp on inside face (brng)



## Type IV-A Fire Resistance Ratings (FRR)




#### FRR & NC Floor Panel Example: 2 HR



## Type IV-A Fire Resistance Ratings (FRR)

IV-A


Primary Frame (3 HR) + Floor Panel Example (2 HR):



How do you determine FRR of MT?

- 2 Options:
- 1. Calculations in Accordance with IBC 722 → NDS Chapter 16
- 2. Tests in Accordance with ASTM E119






#### **MT FRR Calculations Method:**

- IBC 703.3 allows several methods of determining FRR. One is calculations per 722.
- 722.1 refers to NDS Chpt 16 for exposed wood FRR

703.3 Methods for determining fire resistance. The application of any of the methods listed in this section shall be based on the fire exposure and acceptance criteria specified in ASTM E119 or UL 263. The required *fire resistance* of a building element, component or assembly shall be permitted to be established by any of the following methods or procedures:

3. Calculations in accordance with Section 722.

722.1 General. The provisions of this section contain procedures by which the *fire resistance* of specific materials or combinations of materials is established by calculations. These procedures apply only to the information contained in this section and shall not be otherwise used. The calculated *fire resistance* of concrete, concrete masonry and clay masonry assemblies shall be permitted in accordance with ACI 216.1/TMS 0216. The calculated *fire resistance* of steel assemblies shall be permitted in accordance with Chapter 5 of ASCE 29. The calculated *fire resistance* of exposed wood members and wood decking shall be permitted in accordance with Chapter 16 of ANSI/AF&PA *National Design Specification for Wood Construction (NDS)*.







NDS Chapter 16 includes calculation of fire resistance of NLT, CLT, Glulam, Solid Sawn and SCL wood products

#### Table 16.2.1B Effective Char Depths (for CLT

with  $\beta_n=1.5$ in./hr.)

Required Fire Endurance (hr.)	Effective Char Depths, a <sub>char</sub> (in.) lamination thicknesses, h <sub>lam</sub> (in.)								
	5/8	3/4	7/8	1	1-1/4	1-3/8	1-1/2	1-3/4	2
1-Hour	2.2	2.2	2.1	2.0	2.0	1.9	1.8	1.8	1.8
1½-Hour	3.4	3.2	3.1	3.0	2.9	2.8	2.8	2.8	2.6
2-Hour	4,4	4.3	4.1	4.0	3.9	3.8	3.6	3.6	3.6

Nominal char rate of 1.5"/HR is recognized in NDS. Effective char depth calculated to account for duration, structural reduction in heat-affected zone




Table 16.2.1A Char Depth and Effective Char Depth (for  $\beta_n = 1.5$  in./hr.)

Required Fire Resistance (hr.)	Char Depth, a <sub>char</sub> (in.)	Effective Char Depth, a <sub>eff</sub> (in.)
1-Hour	1.5	1.8
1½-Hour	2.1	2.5
2-Hour	2.6	3.2

Table 16.2.1B Effective Char Depths (for CLT with  $\beta_n$ =1.5in./hr.)

Required Fire Endurance	Effective Char Depths, a <sub>char</sub> (in.) lamination thicknesses, h <sub>lam</sub> (in.)								
(hr.)	5/8	3/4	7/8	1	1-1/4	1-3/8	1-1/2	1-3/4	2
1-Hour	2.2	2.2	2.1	2.0	2.0	1.9	1.8	1.8	1.8
1½-Hour	3.4	3.2	3.1	3.0	2.9	2.8	2.8	2.8	2.6
2-Hour	4,4	4.3	4.1	4.0	3.9	3.8	3.6	3.6	3.6

# Structural capacity check performed on remaining section, with stress increases



**Credit: Forest Products Laboratory** 

#### Table 16.2.2 Adjustment Factors for Fire Design<sup>1</sup>

				ASD				
			Design Stress to Member Strength Factor	Size Factor <sup>2</sup>	Volume Factor 2	Flat Use Factor <sup>2</sup>	Beam Stability Factor <sup>3</sup>	Column Stability Factor 3
Bending Strength	$F_{b}$	X	2.85	$C_{F}$	$C_{V}$	$C_{fu}$	$C_L$	-
Beam Buckling Strength	$F_{bE}$	X	2.03	-	-	-	-	-
Tensile Strength	$\mathbf{F}_{t}$	x	2.85	$C_{\mathrm{F}}$	-	-	-	-
Compressive Strength	$F_c$	x	2.58	$C_{F}$	-	-	-	$C_P$
Column Buckling Strength	$F_{cE}$	x	2.03	-	-	-	-	-

$$a_{char} = \beta_t t^{0.813}$$

Solid Sawn, Glulam, SCL

$$a_{char} = n_{lam} h_{lam} + \beta_t (t - (n_{lam} t_{gi}))^{0.813}$$


**CLT** 


$$a_{eff} = 1.2a_{char}$$

**Effective Char Depth** 

#### **Tested Assemblies Method:**

 Many successful Mass Timber ASTM E119 fire tests have been completed by industry & manufacturers







**Contact WoodWorks for Inventory of Tests** 



### Fire-Resistive Design of Mass Timber Members

Code Applications, Construction Types and Fire Ratings

Richard McLain, PE, SE • Senior Technical Director • WoodWorks Scott Breneman, PhD, PE, SE • Senior Technical Director • WoodWorks

For many years, exposed heavy timber framing elements have been permitted in U.S. buildings due to their inherent fire-resistance properties. The predictability of wood's char rate has been well-established for decades and has long been recognized in building codes and standards.

Today, one of the exciting trends in building design is the growing use of mass timber—i.e., large solid wood panel products such as cross-laminated timber (CLT) and nail-laminated timber (NLT)—for floor, wall and roof construction. Like heavy timber, mass timber products have inherent fire resistance that allows them to be left exposed and still achieve a fire-resistance rating. Because of their strength and dimensional stability, these products also offer a low-carbon alternative to steel, concrete, and masonry for many applications. It is this combination of exposed structure and strength that developers and designers across the country

are leveraging to create innovative designs with a warm yet modern aesthetic, often for projects that go beyond traditional norms of wood design.

This paper has been written to support architects and engineers exploring the use of mass timber for commercial and multi-family construction. It focuses on how to meet fire-resistance requirements in the International Building Code (IBC), including calculation and testing-based methods. Unless otherwise noted, references refer to the 2018 IBC.

#### Mass Timber & Construction Type

Before demonstrating fire-resistance ratings of exposed mass timber elements, it's important to understand under what circumstances the code currently allows the use of mass timber in commercial and multi-family construction.

A building's assigned construction type is the main indicator of where and when all wood systems can be used. IBC Saction 602 defines five main options (Type I through V) with all but Type IV having subcategories A and B. Types III and V permit the use of wood framing throughout much of the structure and both are used extensively for modern mass timber buildings.

Type III (IBC 602.3) – Timber elements can be used in floors, roofs and interior walls. Fire-retardant-treated wood (FRTW) framing is permitted in exterior walls with a fireresistance rating of 2 hours or less.

Type V (IBC 602.5) – Timber elements can be used throughout the structure, including floors, roofs and both interior and exterior walls

Type IV (IBC 602.4) – Commonly referred to as 'Heavy Timber' construction, this option



- Code compliance options for demonstrating FRR
- Updated as new tests are completed
- Free download at woodworks.org






#### Demonstrating Fire-Resistance Ratings for Mass Timber Elements in Tall Wood Structures

Richard McLain, PE, SE . Senior Technical Director - Tall Wood, WoodWorks

Changes to the 2021 International Building Code (IBC) have created opportunities for wood buildings that are much larger and taller than prescriptively allowed in past versions of the code. Occupant safety, and the need to ensure fire performance in particular, was a fundamental consideration as the changes were developed and approved. The result is three new construction types—Type IV-A, IV-B and IV-C—which are based on the previous Heavy Timber construction type (renamed Type IV-HT), but with additional fire protection requirements.

One of the main ways to demonstrate that a building will meet the required level of passive fire protection, regardless of structural materials, is through hourly fire-resistance ratings (FRRs) of its elements and assemblies. The IBC defines an FRR as the period of time a building element, component or assembly maintains the ability to confine a fire, continues to perform a given structural function, or both, as determined by the tests, or the methods based on tests, prescribed in Section 703.

FRRs for the new construction types are similar to those required for Type I construction, which is primarily steel and concrete. See Table 1.1 They are found in IBC Table 601, which includes FRR requirements for all construction types and building elements; however, other code sections should be checked for overriding provisions (e.g., occupancy separation, shaft enclosures, etc.) that may alter the requirement.



#### TABLE 1: FRR Requirements (Hours) for Tall Mass Timber Construction Types and Existing Type I

Building Element	I-A Unlimited stories, heights and areas*	IV-A Max. 18 stories, 270 ft, 324,000 sf**	I-B Max. 12 stories, 180 ft, unlimited areas*	IV-B Max. 12 stones, 180 ft, 216,000 sf**	IV-C Max. 9 stones, 85 ft, 135,000 sf**
Primary Frame	3	3	2	2	2

### Demonstrating Fire-Resistance Ratings for Mass Timber Elements in Tall Wood Structures

Free download at woodworks.org

#### **Inventory of Fire Tested MT Assemblies**

#### Table 1: North American Fire Resistance Tests of Mass Timber Floor / Roof Assemblies



CLT Panel	Manufacturer	CLT Grade or Major x Minor Grade	Ceiling Protection	Panel Connection in Test	Floor Topping	Load Rating	Fire Resistance Achieved (Hours)	Source	Testing Lab
3-ply CLT (114mm + 488 in)	Nordic	SPF 1650 Fb 1.3 EMSR 3 SPF #3	2 layers 1/2" Type X gypsum	Half-Lap	None	Reduced 56% Moment Capacity	- u - 1	j (Test I)	NRC Fire Laboratory
3-ply CLT (105mm-4.133 in)	Structurlam	SPF #1/#2 # SPF #1/#2	1 layer 5/8" Type Xgypsum	flatFlap	None	Reduced 7.5% Mannest Capacity	-3-	1 (Test 3)	NRC Fire Laboratory
5-ply CLT (173mm#.875*)	Nordir	Ei	None	Topside Spline	2 staggered layers of 1/2" coment boards	Loaded. See Manufacturer	2	2	NRC Fire Laboratory March 2016
5-ply CLT (175mm6.875*)	Nordic	El	1 layer of 5/8" Type Xgypsum under 2- channels and furning strips with 3 5/8"	Tops ide Spline	2 stagg and layers of 1/2" cement bourds	Loaded. See Manufacturer	1	5	NRC Fire Laboratory Nov 2014
5-ply CLT (175mm6.875*)	Nordie	El	None	Topside Spline	3/4 in proprietary gyperere over Maxxon acoustical mat	Roduced 54% Mament Capacity	(.5	В	UL
5-ply CLT (175mm6.875*)	Nordic	E	l layer 5/8" normal gypsum	Topside Spline	3/A (a. proprietary gyperete a ver Maxxon acoustical mat or proprietary sound board	Rod acod 50% Mament Capacity	2	40	ÜL
5-ply-CLT (175mm6-875*)	Nordie	El	Lisyer 5%* Type X-Gyp ander Resilien (Channel ander 7.7%* Literat with 3.1/2* Mineral Wood feween in its	Half-Lap	None	Loaded. See Mamifacturer	2	21	Interték 8/24/2012
5-ply CLT (175mm6-875*)	Structurlan	EI M5 MSR 2100 & SPF #2	None	Tops ide Spline	1-1/2" Maxxon Cyp-Grete 2000 over Maxxon Bourforcing Mesh	Loaded. See Manufacturer	2.5	6	Intertek, 2/22/2016
5-ply CLT (175mm6.875°)	DR Johnson	VI	No ne	Half-Lap & Tops ide Spline	2° gypsumtopping	Luaded. See Manufacturer	2	7	SwRI (May 2016)
5-ply CLT (175mm6.875*)	Nordic	SPF 1950 Fb MSR a SPF #3	None	Half-Lap	None	Reduced 59% Moment Capacity	(3	(Test-1)	NRC Fire Laboratory
5-ply CLT (175mm6.875°)	Structurlam	SPF #1/#2 # SPF #1/#2	1 layer 5/8° Type Xgypsum	Half-Lap	None	Unreduced 101% Moment Copacity	2	1 (Test 6)	NRC Fire Laboratory
7-ply CLT (245mm 9:65*)	Structurlam	SPF #1/#2 # SPF #1>#2	None	fluff-lap	None	Unreduced 101% Moment Capacity	23	1 (Test 7)	NRC Fire Laboratory
5-ply CLT (175mm#.875*)	SnatLan	SL-V4	None	fiulf-Lap	notional 1/2" ply wood with 8d nails.	Loaded. Sau Manufacturer	1	12 (Test 4)	Western Fire Center 10/26/2016
5-ply CLT (175mm6.875*)	Senart Law	Vi	No ne	Half-Lap	nominal 1/2" plywood with 8d nails.	Loaded. See Manufacturer	2:	12 (Test 5)	Western Fire Center 10/28/2016
5-ply CLT (175mm6 875°)	DR Johnson	VI.	None	Half-Lap	nominal 1/2"plywoodwith #danits.	Lorded. See Mamifacturer	2	(2(Test 6)	Western Fire Center 11/01/2016
5-ply CLT	кин	CVSMI	None	Half-Lap &	Nune	Lizade d.	1	1.8	SwRI



#### **TECHNICAL BRIEF**


# Demonstrating Fire-Resistance Ratings for Mass Timber Elements in Tall Wood Structures

Richard McLain, PE, SE . Senior Technical Director - Tall Wood, WoodWorks

Changes to the 2021 International Building Code (IBC) have created opportunities for wood buildings that are much larger and taller than prescriptively allowed in past versions of the code. Occupant safety, and the need to ensure fire performance in particular, was a fundamental consideration as the changes were developed and approved. The result is three new construction types—Type IV-A, IV-B and IV-C—which are based on the previous Heavy Timber construction type (renamed Type IV-HT), but with additional fire protection requirements.

One of the main ways to demonstrate that a building will meet the required level of passive fire protection, regardless of structural materials, is through hourly fire-resistance ratings (FRRs) of its elements and assemblies. The IBC defines an FRR as the period of time a building element, component or assembly maintains the ability to confine a fire, continues to perform a given structural function, or both, as determined by the tests, or the methods based on tests, prescribed in Section 703.

FRRs for the new construction types are similar to those required for Type I construction, which is primarily steel and concrete. (See Table 1.) They are found in IBC Table 601, which includes FRR requirements for all construction types and building elements; however, other code sections should be checked for overriding provisions (e.g., occupancy separation, shaft enclosures, etc.) that may alter the requirement.



#### TARIF 1:

FRR Requirements (Hours) for Tall Mass Timber Construction Types and Existing Type I

	I-A	IV-A	I-B	IV-B	IV-C
Della Constitution	Unlimited stories,	Max. 18 stories,	Max. 12 stories,	Max. 12 stories,	Max. 9 stories,

### Tall Timber Fire-Resistance Design

# **Materials Permitted**

602.4 Type IV. Type IV construction is that type of construction in which the building elements are mass timber or noncombustible materials and have fire resistance ratings in accordance with Table 601. Mass timber elements shall meet the fire resistance rating requirements of this section based on either the fire resistance rating of the noncombustible protection, the mass timber, or a combination of both and shall be determined in accordance with Section 703.2 or 703.3. The minimum dimensions and permitted materials for building elements shall comply with the provisions of this section and Section 2304.11. Mass timber


Exterior load-bearing walls and nonload-bearing walls shall be mass timber construction, or shall be of noncombustible construction.

**Exception:**Type IV-HT Construction in accordance with Section 602.4.4.

The interior building elements, including nonload-bearing walls and partitions, shall be of mass timber construction or of noncombustible construction.

**Exception:** Type IV-HT Construction in accordance with Section 602.4.4...

# **Type IV-B**



12 STORIES
BUILDING HEIGHT 180 FT
ALLOWABLE BUILDING AREA 648,000 SF
AVERAGE AREA PER STORY 54,000SF

TYPE IV-B









Credit: Susan Jones, atelierjones



# 128

12 STORIES
BUILDING HEIGHT 180 FT
ALLOWABLE BUILDING AREA 648,000 S
AVERAGE AREA PER STORY 54,000SF

TYPE IV-B

Credit: Susan Jones, atelierjones

# **Type IV-B Height and Area Limits**

Occupancy	# of Stories	Height	Area per Story	Building Area
A-2	12	180 ft	90,000 SF	270,000 SF
В	12	180 ft	216,000 SF	648,000 SF
M	8	180 ft	123,000 SF	369,000 SF
R-2	12	180 ft	123,000 SF	369,000 SF

Areas exclude potential frontage increase

In most cases, Type IV-B height & story allowances = Type I-B height & story allowances

Type IV-B area = 2 \* Type IV-HT area

# Credit: Kaiser+Path

# IV-B

# Type IV-B Protection vs. Exposed



12 STORIES
BUILDING HEIGHT 180 FT
ALLOWABLE BUILDING AREA 648,000 SF
AVERAGE AREA PER STORY 54,000SF

TYPE IV-B

Credit: Susan Jones, atelierjones






### NC protection on all surfaces of Mass Timber except limited exposed areas

~20% of Ceiling or ~40% of Wall can be exposed

# Type IV-B Fire Resistance Ratings (FRR)

IV-B





Primary Frame FRR

Ext or Int Bearing Wall FRR

Floor Construction FRR


**Roof Construction FRR** 

2 HR (1 HR at Roof)

2 HR

2 HR

1 HR



# Type IV-B Fire Resistance Ratings (FRR)

IV-B





\*Applicable to most locations. Limited exposed MT permitted

FRR	Protection
2 HR (1 HR at Roof)	80 min* (40 min* at Roof)
2 HR	80 min*
2 HR	80 min*
1 HR	40 min*

Primary Frame FRR


Ext or Int Bearing Wall FRR

Floor Construction FRR

**Roof Construction FRR** 

1/2" Type X Gypsum = 25 min

5/8" Type X Gypsum = 40 min



# **Type IV-B Protection**







Floor Surface Protection

**Roof Construction Protection** 

**Ext Wall Protection** 

Min. 1 inch of NC protection

Min. 1 layer 5/8" type X gyp on inside face\*

Min. 1 layer 5/8" type X gyp on outside face

Min. 2 layers 5/8" type X gyp on inside face\*


\*Applicable to most locations Limited exposed MT permitted



# Type IV-B Fire Resistance Ratings (FRR)

IV-B

#### FRR & NC Floor Panel Example: 2 HR




\*Applicable to most locations. Limited exposed MT permitted

# Type IV-B Fire Resistance Ratings (FRR)

IV-B

#### Primary Frame (2 HR) + Floor Panel Example (2 HR):



IV-B

#### Limited Exposed MT allowed in Type IV-B for:

- MT beams and columns which are not integral part of walls or ceilings, no area limitation applies
- MT ceilings and beams up to 20% of floor area in dwelling unit or fire area, or
- MT walls and columns up to 40% of floor area in dwelling unit or fire area, or
- Combination of ceilings/beams and walls/columns, calculated as follows:



Credit: Kaiser+Path

IV-B

Mixed unprotected areas, exposing both ceilings and walls:

In each dwelling unit or fire area, max.
 unprotected area =


$$(U_{tc}/U_{ac}) + (U_{tw}/U_{aw}) \le 1.0$$

- U<sub>tc</sub> = Total unprotected MT ceiling areas
- U<sub>ac</sub> = Allowable unprotected MT ceiling areas
- U<sub>tw</sub> = Total unprotected MT wall areas
- U<sub>aw</sub> = Allowable unprotected MT wall areas



Credit: Kaiser+Path

#### Design Example: Mixing unprotected MT walls & ceilings



#### 800 SF dwelling unit

- $U_{ac} = (800 \text{ SF})*(0.20) = 160 \text{ SF}$
- $U_{aw} = (800 \text{ SF})*(0.40) = 320 \text{ SF}$
- Could expose 160 SF of MT ceiling,
   OR 320 SF of MT Wall, OR
- If desire to expose 100 SF of MT ceiling in Living Room, determine max. area of MT walls that can be exposed

#### Design Example: Mixing unprotected MT walls & ceilings



$$(U_{tc}/U_{ac}) + (U_{tw}/U_{aw}) \le 1.0$$
  
(100/160) +  $(U_{tw}/320) \le 1.0$   
 $U_{tw} = 120 \text{ SF}$ 


 Can expose 120 SF of MT walls in dwelling unit in combination with exposing 100 SF of MT ceiling





IV-B





IV-B

#### Horizontal separation of unprotected areas:

 Unprotected portions of mass timber walls and ceilings shall be not less than 15 feet from unprotected portions of other walls and ceilings, measured horizontally along the ceiling and from other unprotected portions of walls measured horizontally along the floor.



Credit: Kaiser+Path

IV-B





# Type IV-C



9 STORIES
BUILDING HEIGHT 85'
ALLOWABLE BUILDING AREA 405,000 SF
AVERAGE AREA PER STORY 45,000 SF

TYPE IV-C



Photos: Baumberger Studio/PATH Architecture/Marcus Kauffman







Credit: Susan Jones, atelierjones





9 STORIES
BUILDING HEIGHT 85'
ALLOWABLE BUILDING AREA 405,000 SF
AVERAGE AREA PER STORY 45,000 SF

TYPE IV-C

Credit: Susan Jones, atelierjones

# **Type IV-C Height and Area Limits**

Occupancy	# of Stories	Height	Area per Story	Building Area
A-2	6	85 ft	56,250 SF	168,750 SF
В	9	85 ft	135,000 SF	405,000 SF
M	6	85 ft	76,875 SF	230,625 SF
R-2	8	85 ft	76,875 SF	230,625 SF

Areas exclude potential frontage increase

In most cases, Type IV-C height allowances = Type IV-HT height allowances, but add'l stories permitted due to enhanced FRR

Type IV-C area = 1.25 \* Type IV-HT area

# IV-C

# Type IV-C Protection vs. Exposed



9 STORIES
BUILDING HEIGHT 85'
ALLOWABLE BUILDING AREA 405,000 SF
AVERAGE AREA PER STORY 45.000 SF

TYPE IV-C

Credit: Susan Jones, atelierjones





All Mass Timber surfaces may be exposed

**Exceptions: Shafts, concealed spaces, outside face of exterior walls** 

Credit: Kaiser+Path, Ema Peter

# Type IV-C Fire Resistance Ratings (FRR)







Primary Frame FRR

Ext or Int Bearing Wall FRR

Floor Construction FRR

**Roof Construction FRR** 

2 HR (1 HR at Roof)

2 HR

2 HR

1 HR



Same FRR as IV-B, but all MT in IV-C may be exposed\*

# **Type IV-C Protection**







Floor Surface Protection


**Roof Construction Protection** 

**Ext Wall Protection** 

None req'd

None req'd


Min. 1 layer 5/8" type X gyp on outside face None req'd on inside face



# Type IV-C Fire Resistance Ratings (FRR)

IV-C


#### FRR & NC Floor Panel Example: 2 HR



# Type IV-C Fire Resistance Ratings (FRR)

IV-C

Primary Frame (2 HR) + Floor Panel Example (2 HR):



# Fire Resistance Ratings (FRR) Recap













Roof	Constr	ruction
11001	COHSU	action

Primary Frame @ Roof

Floor Construction

**Primary Frame** 


**Exterior Bearing Walls** 

**Interior Bearing Walls** 

1.5	1	1	нт
2	1	1	нт
2	2	2	нт
3	2	2	нт
3	2	2	2
3	2	2	1 or HT

# Noncombustible Protection (NC) Recap

Noncombustible Protection Required















Credit: LEVER Architecture

Credit: PATH Architecture

Photo: Blaine Brownell

# **Interior Wall Construction Recap**




Fire Rating (bearing wall)

Construction - MT

**NC Protection** 

Noncombustible non-bearing wall

**Wood Stud Wall** 




3 Hr	2 Hr	2 Hr	1 Hr or HT*				
Laminated construction 4" thick (CLT, NLT, etc) Solid wood construction min. 2 layers of 1" matched boards							
Pe	No						
	1 Hr						
	1 Hr						

<sup>\*</sup>IBC 2021 requires at least 1 Hr FRR for HT walls supporting 2 levels

# **Exterior Wall Construction Recap**







**IBC 2018** 

**Mass Timber** 

**Exterior NC Protection** 

Interior NC Protection

**Light Frame FRTW** 

2 Hr	2 Hr	2 Hr	2Hr
Mass Timber/CLT		4" min thick <u>CLT</u> *	6" <u>Wall</u> *
40 Min NC & No Exterior Combustible Coverings		FRT Sheathing, Gyp or other NC	
Per Interior Requirements		Not Required	
No		Yes*	6" Wall*
	ass Timber/0 40 Min NC & or Combustible erior Require	ass Timber/CLT  40 Min NC & or Combustible Coverings  erior Requirements	ass Timber/CLT  4" min thick <u>CLT</u> *  40 Min NC & FRT Sheathing, erior Requirements  Not Re

IBC 2021

<sup>\*</sup>Changes in IBC 2015, 2018, and 2021 editions

#### What's the 'Sweet Spot' for Tall Mass Timber?

#### **Depends on many factors:**


- Project Use
- Site Constraints
- Local Zoning & FAR Limitations
- Budget
- Client Objectives for Sustainability, Exposed Timber
- And More...

**But Some General Trends Could Be:** 

80 M Street, SE, Washington, DC Photo: Hickok Cole | Architect: Hickok Cole

### **Type IV-C Tall Mass Timber**

#### **Example R-2, Type IV-C Building**




Not Likely to Utilize Podium Due to Overall Building Height Limit (85 ft) Relative to # of Timber Stories (8)


Same Overall Building Height Limit as IV-HT (85 ft) but higher Fire-Resistance Ratings Req'd

3 Additional Stories Permitted Compared to IV-HT

All Timber Exposed

### **Type IV-B Tall Mass Timber**





**Example Mixed-Use, Type IV-B Building** 

Likely to Utilize Podium Due to Overall Building Height Limit (180 ft) Relative to # of Timber Stories (12)


Same Fire-Resistance Ratings Req'd as IV-C But Limitations on Timber Exposed

4 Additional Stories Permitted Compared to IV-C

**Limited Timber Exposed** 

### **Type IV-A Tall Mass Timber**

Timber, R-2: 18 Stories 184,500 SF Roof max per floor 553,500 SF Grad bldg. (areas noted assume no frontage increase) Multi-Story Type IA Podium



**Example Mixed-Use, Type IV-A Building** 

Likely to Utilize Podium Due to Overall Building Height Limit (270 ft) Relative to # of Timber Stories (18)

Higher Fire-Resistance Ratings Req'd than IV-B For Primary Frame

6 Additional Stories Permitted Compared to IV-B


No Exposed Timber Permitted



# **Concealed Spaces in Type IV**


What if I have a dropped ceiling? Can I have a dropped ceiling?

Impact on FRR, NC placement, sprinkler requirements



# **Concealed Spaces in Type IV**

#### Previous Type IV (now IV-HT) provisions prohibited concealed spaces



Credit: IBC


# **Concealed Spaces in Type IV-HT**

# Type IV-HT (IBC 2021) permits concealed spaces where one of the following conditions exists:

- 1. The building is sprinklered throughout with an NFPA 13 Sprinkler and automatic sprinklers are provided in the concealed space.
- 2. The concealed space is completely filled with noncombustible insulation.
- 3. Surfaces within the concealed space are fully sheathed with not less than 5/8" Type X gypsum.

Concealed spaces within interior walls and partitions with a one hour or greater fire resistance rating complying Section 2304.11.2.2 do not require additional protection.

# **Concealed Spaces in Type IV-HT**




# Concealed Spaces in Type IV-A, IV-B, IV-C

New IV-HT concealed space provisions do not apply to IV-A, IV-B or IV-C


But, can still have concealed spaces in IV-A, IV-B, IV-C:

- IV-A and IV-B: Combustible construction forming concealed spaces protected with NC of 80 minutes (2 layers of 5/8" Type X Gypsum)
- IV-C: Combustible construction forming concealed spaces protected with NC of 40 minutes (1 layer of 5/8" Type X Gypsum)






# Concealed Spaces in Type IV-A, IV-B



# **Concealed Spaces in Type IV-C**





### Concealed Spaces in Mass Timber and Heavy Timber Structures

Richard McLain, PE, SE . Senior Technical Director - Tall Wood, WoodWorks

Concealed spaces, such as those created by a dropped ceiling in a floor/ceiling assembly or by a stud wall assembly, have unique requirements in the International Building Code (IBC) to address the potential of fire spread in non-visible areas of a building. Section 718 of the 2018 IBC includes prescriptive requirements for protection and/or compartmentalization of concealed spaces through the use of draft stopping, fire blocking, sprinklers, and other means. For information on these requirements, see the WoodWorks O&A, Are sprinklers required in concealed spaces such as floor and roof cavities in multi-family wood-frame buildings?

For mass timber building elements, the choice of construction type can have a significant impact on concealed space requirements. Because mass timber products such as crosslaminated timber (CLT) are prescriptively recognized for Type IV construction, there is a common misperception that exposed mass timber building elements cannot be used or exposed in other construction types. This is not the case. In addition to Type IV buildings, structural mass timber elements—including CLT, glued-laminated timber (glulam), nail-laminated timber (NLT), structural composite lumber (SCL), and tongue-and-groove (T&G) decking—can be utilized and exposed in the following construction types, whether or not a fire-resistance rating is required:

- Type III Floors, roofs and interior walls may be any material permitted by code, including mass timber; exterior walls are required to be noncombustible or fire retardant-treated wood.
- Type V Floors, roofs, interior walls, and exterior walls (i.e., the entire structure) may be constructed of mass timber.
- Types I and II Mass timber may be used in select circumstances such as roof construction—including the primary frame in the 2021 IBC—in Types I-B, II-A or II-B; exterior columns and arches when 20 feet or more of horizontal separation is provided; and balconies, canopies and similar projections.



#### **Concealed Space Protection in Mass Timber**



#### **CLT Fire Performance – Char Fall Off**

CLT char fall off or heat induced delamination occurs when laminations (or pieces thereof) fall off the underside of a CLT panel under extended fire conditions.





#### **CLT Fire Performance – Fire Re-Growth**

In tall buildings, preventing fire re-growth is key.

Fire re-growth is a phenomenon in which the heat-release rate of a fire intensifies following a decay phase. Fire re-growth can be initiated when delamination occurs, as this exposes un-charred wood surfaces, thereby resulting in an influx of fuel available for consumption by the fire.





#### **CLT Fire Performance – Char Fall Off**

#### **Facts about CLT char fall off:**

- Only an item to consider in tall buildings. Important to avoid in high-rise construction where required performance is containment of fire within compartment of origin with no sprinkler or fire service suppression
- Not applicable when discussing mid-rise mass timber (or any building under types II, III, IV-HT or V)
- Largely a function of adhesive performance under high temps
- Has been addressed in PRG 320-18 (required for all CLT under 2021 IBC, not just tall wood)




#### **CLT Fire Performance – PRG 320**

#### 2021 IBC Section 602.4 added:

Cross-laminated timber shall be labeled as conforming to PRG 320 - 18 as referenced in Section 2303.1.4.







#### **CLT Fire Performance – PRG 320**

PRG 320 is manufacturing & performance standard for CLT.

2018 edition (referenced in 2021 IBC) added new elevated temperature adhesive performance requirements validated by full-scale and medium-scale qualification testing to ensure CLT does not exhibit fire re-growth

When designing tall wood – specify CLT per PRG 320-18 (req'd in IBC 2021 for all CLT)

ANSI/APA PRG 320-2018

Standard for Performance-Rated Cross-Laminated Timber



ANNEX B. PRACTICE FOR EVALUATING ELEVATED TEMPERATURE PERFORMANCE OF ADHESIVES USED IN CROSS-LAMINATED TIMBER (MANDATORY)



# Tall Wood Buildings in the 2021 IBC Up to 18 Stories of Mass Timber

Scott Breneman, PhD, SE, WoodWorks - Wood Products Council • Matt Timmers, SE, John A. Martin & Associates
• Dennis Richardson, PE, CBO, CASp, American Wood Council

In January 2019, the International Code Council (ICC) approved a set of proposals to allow tall wood buildings as part of the 2021 International Building Code (IBC). Based on these proposals, the 2021 IBC will include three new construction types—Type IV-A, IV-B and IV-C—allowing the use of mass timber or noncombustible materials. These new types are based on the previous Heavy Timber construction type (renamed Type IV-HT) but with additional fire-resistance ratings and levels of required noncombustible protection. The code will include provisions for up to 18 stories of Type IV-A construction for Business and Residential Occupancies.

Based on information first published in the Structural Engineers Association of California (SEAOC) 2018 Conference Proceedings, this paper summarizes the background to these proposals, technical research that supported their adoption, and resulting changes to the IBC and product-specific standards.

#### Background: ICC Tall Wood Building Ad Hoc Committee

Over the past 10 years, there has been a growing Interest in tall buildings constructed from mass timber materials (Breneman 2013, Timmers 2015). Around the world there are now dozens of timber buildings constructed above eight stories tall. Some international examples include:





#### WoodWorks Tall Wood Design Resource

Via Cenni Milan, Italy 9 2013

