

#### Mass Timber in Florida: 4Roots Regenerative Urban Farm Education Building

June 1, 2023

Presented by Jeff Peters, PE, CGC, WoodWorks Philip Donovan and Pete Hall, Little Diversified Architectural Consulting "The Wood Products Council" is a Registered Provider with The American Institute of Architects Continuing Education Systems (AIA/CES), Provider #G516.

Credit(s) earned on completion of this course will be reported to AIA CES for AIA members. Certificates of Completion for both AIA members and non-AIA members are available upon request. This course is registered with AIA CES for continuing professional education. As such, it does not include content that may be deemed or construed to be an approval or endorsement by the AIA of any material of construction or any method or manner of handling, using, distributing, or dealing in any material or product.



Questions related to specific materials, methods, and services will be addressed at the conclusion of this presentation.

# **Course Description**

Mass timber is a unique, non-commodity building material and, to lay the groundwork for success, certain critical decisions must be made as early as possible. These decisions can have a big impact on cost and can either increase or limit opportunities later in design. There are many cases of project teams that want to realize the full benefits of mass timber, but, because they base their designs on traditional building practices instead of optimizing them for mass timber, end up with avoidable price premiums. This presentation will walk through early project decisions and design steps, focusing on how to optimize projects for mass timber and how one early decision can influence others. Topics will include construction types, fire ratings, column grids and beam/panel spans, acoustics and MEP integration. Completed mass timber projects will be used to illustrate the variety of viable options when navigating these key decisions.

# Learning Objectives

- 1. Identify construction types within the International Building Code where a mass timber structure is permitted.
- 2. Discuss the impacts of construction type on required fire-resistance ratings of structural elements, noting the impacts that these ratings have on effective member spans and resulting grids.
- 3. Review code-compliance requirements for acoustics and primary frame connections and provide solutions for meetings these requirements with tested mass timber assemblies.
- 4. Highlight effective methods of integrating MEP services in a mass timber building and discuss the relative impacts of each on cost, aesthetics, occupant comfort and future tenant renovations.



One *potential* design route:

- 1. Building size & occupancy informs construction type
- 2. Construction type informs fire resistance ratings
- 3. Grid & fire resistance ratings inform timber member sizes & MEP layout

But that's not all...





#### **Construction Type –** Primarily based on building size & occupancy

	Construction Type (All Sprinklered Values)								
	IV-A	IV-B	IV-C	IV-HT	III-A	III-B	V-A	V-B	
Occupancies	Allowable Building Height above Grade Plane, Feet (IBC Table 504.3)								
A, B, R	270	180	85	85	85	85	70	60	
	Allowable Number of Stories above Grade Plane (IBC Table 505.4)								
A-2, A-3, A-4	18	12	6	4	4	3	3	2	
В	18	12	9	6	6	4	4	3	
R-2	18	12	8	5	5	5	4	3	
	Allowable Area Factor (At) for SM, Feet <sup>2</sup> (IBC Table 506.2)								
A-2, A-3, A-4	135,000	90,000	56,250	45,000	42,000	28,500	34,500	18,000	
В	324,000	216,000	135,000	108,000	85,500	57,000	54,000	27,000	
R-2	184,500	123,000	76,875	61,500	72,000	48,000	36,000	21,000	

#### **Construction Type –** Primarily based on building size & occupancy

	Construction Type (All Sprinklered Values)								
	IV-A	IV-B	IV-C	IV-HT	III-A	III-B	V-A	V-B	
Occupancies	Allowable Building Height above Grade Plane, Feet (IBC Table 504.3)								
A, B, R	270	180	85	85	85	85	70	60	
For lo	For low- to mid-rise mass timber buildings, there may be								
Amultipl	e opti	ons <sup>°</sup> for	const	ruction	type.	There a	re pros	and	
	of each, don't assume that one type is always best.								
cons c	of eacl	h, don'i	t assun	ne that	one ty	pe is al	lways b	est.	
CONS C	of eacl	n, don't	t assun	ne that	one ty	pe is al ₅	lways b	est. ₃	
Cons o R-2	of eacl	n, don't Allov	t assun wable Area I	ne that 5 Factor (At) fo	one ty 5 or SM, Feet <sup>2</sup>	pe is a 5 (IBC Table	ways k 506.2)	est. 3	
CONS ( R-2 A-2, A-3, A-4	<b>of eacl</b> 18 135,000	n, don't 12 Allov 90,000	t assun wable Area I 56,250	ne that 5 Factor (At) fo 45,000	one ty or SM, Feet <sup>2</sup> 42,000	pe is al (IBC Table 28,500	ways k 506.2) 34,500	<b>18,000</b>	
CONS ( R-2 A-2, A-3, A-4 B	<b>of eacl</b> 135,000 324,000	n, don't 12 Allov 90,000 216,000	t assun wable Area I 56,250 135,000	ne that 5 Factor (At) fo 45,000 108,000	<b>one ty</b> or SM, Feet <sup>2</sup> 42,000 85,500	pe is a 5 (IBC Table 28,500 57,000	ways k 506.2) 34,500 54,000	18,000 27,000	



# When does the code allow mass timber to be used?

IBC defines mass timber systems in Chapter 2 and notes their acceptance and manufacturing standards in IBC Chapter 23

Permitted anywhere that combustible materials and heavy timber are allowed, plus more



IBC defines 5 construction types: I, II, III, IV, V A building must be classified as one of these

Construction Types I & II: All elements required to be non-combustible materials

However, there are exceptions including several for mass timber

#### Where does the code allow MT to be used?

<u>Type IB & II</u>: Roof Decking



All wood framed building options:

#### Type III Exterior walls non-combustible (may be FRTW)

interior elements any allowed by code, including mass timber

Type V

All building elements that are allowed by code, including mass timber

Types III and V are subdivided to A (protected) and B (unprotected)

Type IV (Heavy Timber)

Exterior walls non-combustible (may be FRTW OR CLT) Interior elements qualify as Heavy Timber (min. sizes, no concealed spaces except in 2021 IBC)

Photo Credit: Hacker Architects, Jeremy Bittermann

# Type IV construction permits exposed heavy/mass timber elements of min. sizes.

Framing		Solid Sawn (nominal)	Glulam (actual)	SCL (actual)		
or	Columns	8 x 8	6 <sup>3</sup> / <sub>4</sub> x 8¼	7 x 7½		
Flo	Beams	6 x 10	5 x 10½	5¼ x 9½		
of	Columns	6 x 8	5 x 8¼	5¼ x 7½		
Ro	Beams*	4 x 6	3 X 6 <sup>7</sup> / <sub>8</sub>	3½ X 5½		

#### Minimum Width by Depth in Inches See IBC 2018 2304.11 or IBC 2015 602.4 for Details

\*3" nominal width allowed when sprinklered



#### Type IV concealed spaces

Until 2021 IBC, Type IV-HT provisions prohibited concealed spaces



Credit: IBC

#### Type IV concealed space options within 2021 IBC



#### Type IV concealed space options within 2021 IBC



#### Type IV concealed space options within 2021 IBC



#### **Concealed spaces solutions paper**



Concealed spaces, such as those created by a dropped celling in a floor/celling assembly or by a stud wall assembly, have unique requirements in the International Building Code (IBC) to address the potential of fire spread in nonvisible areas of a building. Section 718 of the 2018 IBC includes prescriptive requirements for protection and/or compartmentalization of concealed spaces through the use of draft stopping, fire blocking, sprinklers and other means. For information on these requirements, see the WoodWork's Q&A, Are sprinklers required in concealed spaces such as floor and roof cavities in multi-family wood-frame buildings?<sup>1</sup>

For mass timber building elements, the choice of construction type can have a significant impact on concealed space requirements. Because mass timber products such as cross-laminated timber (CLT) are prescriptively recognized for Type IV construction, there is a common misperception that exposed mass timber building elements cannot be used or exposed in other construction types. This is not the case. In addition to Type IV buildings, structural mass timber elements—including CLT; glue-laminated timber (glulam), nail-laminated timber (NCL), structural composite lumber (SCL), and tongue-and-groove (T&G) decking—can be utilized and exposed in the following construction types, whether or not a fire-resistance rating is required:

- Type III Floors, roofs and interior walls may be any material permitted by code, including mass timber; exterior walls are required to be noncombustible or fire retardant-treated wood.
- Type V Floors, roofs, interior walls and exterior walls
  (i.e., the entire structure) may be constructed of mass timber.
- Types I and II Mass timber may be used in select circumstances such as roof construction – including the primary frame in the 2021 IBC – In Types I-8, II-A or II-8; exterior columns and arches when 20 feet or more of horizontal separation is provided; and balconies, canopies and similar projections.





https://www.woodworks.org/wp-content/uploads/wood\_solution\_paper-Concealed Spaces Timber Structures.pdf



Allowable mass timber building size for group B & R occupancy with NFPA 13 Sprinkler



Type III: 6-stories (B) 5-stories (R)



Type V: 4-stories (B) 4-stories (R)

Type IV: 6-stories (B) | 5-stories (R)





# **Member Sizes**

- Impact of FRR on sizing
- Impact of sizing on efficient spans
- Consider connections can drive member sizing









### **Fire-Resistance Ratings**

- Driven primarily by construction type
- Rating achieved through timber alone or non-com protection required?

TARLE 601

FIRE-RESISTANCE	RATIN	G REQU	IREME	NTS F	OR BUI	LDING	ELEME	INTS (I	HOURS	5)		
BUILDING ELEMENT		TYPEI		TYPE II		TYPE III		TYPE IV			TYPE V	
		В	Α	В	Α	В	A	В	С	HT	Α	В
Primary structural frame <sup>f</sup> (see Section 202)	34.6	2ª, b, c	1 <sup>b, c</sup>	0°	1 <sup>b, c</sup>	0	3*	2ª	2ª	HT	1 <sup>b, c</sup>	0
Bearing walls												
Exterior <sup>•.f</sup>	3	2	1	0	2	2	3	2	2	2	1	0
Interior	3*	2ª	1	0	1	0	3	2	2	1/HT <sup>s</sup>	1	0
Nonbearing walls and partitions Exterior						See 7	Table 70	5.5				
Nonbearing walls and partitions Interior <sup>d</sup>		0	0	0	0	0	0	0	0	See Section 2304.11.2	0	0
Floor construction and associated secondary structural members (see Section 202)	2	2	1	0	1	0	2	2	2	HT	1	0
Roof construction and associated secondary structural members (see Section 202)		1 <sup>b,c</sup>	1 <sup>b,c</sup>	0°	1 <sup>b,c</sup>	0	1 <sup>1</sup> / <sub>2</sub>	1	1	HT	1 <sup>b,c</sup>	0

# **Fire-Resistance Ratings (FRR)**

- Thinner panels (i.e. 3-ply) generally difficult to achieve a 1+ hour FRR
- 5-ply CLT / 2x6 NLT & DLT panels can usually achieve a 1- or 2hour FRR
- Construction Type | FRR | Member Size | Grid (or re-arrange that process but follow how one impacts the others)

Panel	Example Floor Span Ranges
3-ply CLT (4-1/8" thick)	Up to 12 ft
5-ply CLT (6-7/8" thick)	14 to 17 ft
7-ply CLT (9-5/8")	17 to 21 ft
2x4 NLT	Up to 12 ft
2x6 NLT	10 to 17 ft
2x8 NLT	14 to 21 ft
5" MPP	10 to 15 ft



Construction type influences FRR

- Type IV-HT Construction ullet
  - (minimum sizes: Section 2304.11)
- **Other than type IV-HT**: Demonstrated fire resistance

Method of demonstrating FRR (calculations or testing) can impact member sizing



in s

Page 1 of 53

₩<sup>cc</sup>

**Fire Testing** 

Laboratory

ber 4, 2019

TEST REPORT

American Wood Council 2 Catoctin Circle SE, Suite 201

Leesburg, VA 20175 Standard Methods of Fire Tests of Building Construction and Materials ASTM E 119 - 11a

NGC

#### Which Method of Demonstrating FRR of MT is Being Used?

- 1. Calculations in Accordance with IBC 722 → NDS Chapter 16
- 2. Tests in Accordance with ASTM E119





Unexposed surface

Fire exposed surface

# FRR Design of MT

#### Calculated FRR of Exposed MT: IBC to NDS code compliance path



Code Path for Exposed Wood Fire-Resistance Calculations

#### IBC 703.3

#### Methods for determining fire resistance

- Prescriptive designs per IBC 721.1
- Calculations in accordance with IBC 722
- · Fire-resistance designs documented in sources
- · Engineering analysis based on a comparison
- Alternate protection methods as allowed by 104.11

#### IBC 722 Calculated Fire Resistance

"The calculated *fire resistance* of exposed wood members and wood decking shall be permitted in accordance with Chapter 16 of ANSI/AWC National Design Specification for Wood Construction (NDS)

#### NDS Chapter 16 Fire Design of Wood Members

- · Limited to calculating fire resistance up to 2 hours
- Char depth varies based on exposure time (i.e., fire-resistance rating), product type and lamination thickness. Equations and tables are provided.
- TR 10 and NDS commentary are helpful in implementing permitted calculations.

### **FRR Design of MT**

CLT Pand

3-ply CLT

(11dmm.d.488.in)

3-ply CLT

(105mm 4.133 in)

S-ply CLT

(175mm6.875\*)

5-ply CLT

(175mm6.875\*)

5-ply CLT

(175mm 6.875\*)

5-ply CLT

(175mm6.875\*)

5-ply CLT

(175mm6.875\*)

S-ply CLT

(175mm6.875\*)

5-ply CLT

(175mm6.875\*)

5-ply CLT

(175mm6.875\*)

3-ply CLT

(175mm 6 875\*)

7-ply CLT

(245mm 9.65\*)

5-ply CLT

(175mm6.875\*)

5-ply CLT

1175mm6 8754

5-ply CLT

(175mm6.875\*)

5-plvCLT

11 Adams in 2 ? 5

SmartLam

DR Johnson

KLH

V1

V1

CV3M1

None

Nine

None

Half-Lap

Half-Lap

Half-Lap &

Tonside unline

#### **WoodWorks Inventory of Fire Tested MT Assemblies**

#### Table 1: North American Fire Resistance Tests of Mass Timber Floor / Roof Assemblies



nominal 1/2" ply wood with 8d nails.

pominal 1/2" ply used with 8d nails.

None

WOODWORKS

WOOD PRODUCTS COUNCIL

12 (Test 5)

12 (fest 6)

18

10/28/2016 Western Fire Center

11/01/2016

SwRI

2

2

See Manufacturer

Landed

See Manufacturer

Loaded.

Cas Manufactions

#### **FRR Design of MT**



#### Fire-Resistive Design of Mass Timber Members

**Code Applications, Construction Types and Fire Ratings** 

Richard McLain, PE, SE • Senior Technical Director • WoodWorks Scott Breneman, PRD, PE, SE • Senior Technical Director • WoodWorks

For many years, exposed heavy timber framing elements have been permitted in U.S. buildings due to their inherent fire-resistance properties. The predictability of wood's char rate has been well-estabilished for decades and has long been recognized in building codes and standards.

Today, one of the exciting trends in building design is the growing use of mass timber—i.e., large solid wood panel products such as cross-laminated timber (CLT) and naillaminated timber (NLT)—for floor, wall and roof construction. Like heavy timber, mass timber products have inherent fire resistance that allows them to be left exposed and still achieve a fire-resistance rating. Because of their strength and dimensional stability, these products also offer a lowcarbon alternative to steel, concrete, and masonry for many applications. It is this combination of exposed stores the country thrength the developers and designers across the country are leveraging to create innovative designs with a warm yet modern aesthetic, often for projects that go beyond traditional norms of wood design.

This paper has been written to support architects and engineers exploring the use of mass timber for commercial and multi-family construction. It focuses on how to meet fire-resistance requirements in the International Building Code IIBC), including calculation and testing-based methods. Unless otherwise noted, references refor to the 2016 IBC.

#### Mass Timber & Construction Type

Before demonstrating fire-resistance ratings of exposed mass timber elements, it's important to understand under what circumstances the code currently allows the use of mass timber in commercial and multi-family construction.



commercial and multi-family construction. A building's assigned construction type is the main indicator of where and when all wood systems can be used. IBC Section 602 defines five main options (Type I through V) with all but Type IV having subcategories A and B. Types III and V permit the use of wood framing throughout much of the structure and both are used extensively for modern mass timber buildings.

Type III (IBC 602.3) – Timber elements can be used in floors, roofs and interior walls. Fire-retardant-treated wood (FRTW) framing is permitted in exterior walls with a fireresistance rating of 2 hours or less.

Type V (IBC 602.5) – Timber elements can be used throughout the structure, including floors, roofs and both interior and exterior walls.

Type IV (IBC 602.4) – Commonly referred to as 'Heavy Timber' construction, this option

#### Mass Timber Fire Design Resource

- Code compliance options for demonstrating FRR
- Free download at woodworks.org



# **Grids & Spans**

- Consider Efficient Layouts
- Repetition & Scale
- Manufacturer Panel Sizing
- Transportation



# **Grids & Spans**

- Consider Efficient
  Layouts
- Repetition & Scale
- Manufacturer Panel Sizing
- Transportation



#### **Member Sizes**

- Impact of FRR on Sizing
- Impact of Sizing on Efficient Spans
- Consider connections can drive member sizing

#### 0 HR FRR: Consider 3-ply Panel

- Efficient Spans of 10-12 ft
- Grids of 20x20 (1 purlin) to 30x30 (2 purlins) may be efficient

Platte Fifteen, Denver, CO 30x30 Grid, 2 purlins per bay 3-ply CLT Image: JC Buck



#### **Member Sizes**

- Impact of FRR on Sizing
- Impact of Sizing on Efficient Spans
- Consider connections can drive member sizing

#### 1 or 2 HR FRR: Likely 5-ply Panel

- Efficient spans of 14-17 ft
- Grids of 15x30 (no purlins) to 30x30 (1 purlin) may be efficient

Clay Creative, Portland, OR 30x30 Grid, 1 purlin per bay 2x6 NLT Image: Mackenzie


#### Why so much focus on panel thickness?



#### **Typical MT Package Costs**



Source: Swinerton



Panels are the biggest part of the biggest piece of the cost pie

Source: Swinerton

## **Construction Type Early Decision Example**



#### 7-story building on health campus

- Group B occupancy, NFPA 13 sprinklers throughout
- Floor plate = 22,300 SF
- Total Building Area = 156,100 SF

#### **MT Construction Type Options:**

- If Building is < 85 ft</li>
  - 7 stories of IV-C
  - 6 stories of IIIA or IV-HT over 1 story IA podium
- If Building is > 85 ft
  - 7 stories of IV-B

#### Panel volume usually 65-80% of MT package volume



Source: Fast + Epp, Timber Bay Design Tool

#### **Type IIIA option 1**

1-hr FRR Purlin: 5.5"x28.5" Girder: 8.75"x33" Column: 10.5"x10.75" Floor panel: 5-ply

Glulam volume = 118 CF (22% of MT) CLT volume = 430 CF (78% of MT) Total volume = 0.73 CF / SF

#### Panel volume usually 65-80% of MT package volume



Source: Fast + Epp, Timber Bay Design Tool

#### **Type IIIA option 2**

1-hr FRR Purlin: 5.5"x24" Girder: 8.75"x33" Column: 10.5"x10.75" Floor panel: 5-ply

Glulam volume = 123 CF (22% of MT) CLT volume = 430 CF (78% of MT) Total volume = 0.74 CF / SF

Cost considerations: One additional beam (one additional erection pick), 2 more connections

#### Panel volume usually 65-80% of MT package volume



Source: Fast + Epp, Timber Bay Design Tool

## Type IV-HT

0-hr FRR (min sizes per IBC) Purlin: 5.5"x24" (IBC min = 5"x10.5") Girder: 8.75"x33" (IBC min = 5"x10.5") Column: 10.5"x10.75" (IBC min = 6.75"x8.25") Floor panel: 3-ply (IBC min = 4" CLT)

Glulam volume = 120 CF (32% of MT) CLT volume = 258 CF (68% of MT) Total volume = 0.51 CF / SF

#### Panel volume usually 65-80% of MT package volume



Source: Fast + Epp, Timber Bay Design Tool

**Type IV-C** 2-hr FRR Purlin: 8.75"x28.5" Girder: 10.75"x33" Column: 13.5"x21.5" Floor panel: 5-ply

Glulam volume = 183 CF (30% of MT) CLT volume = 430 CF (70% of MT) Total volume = 0.82 CF / SF

#### Which is the most efficient option?



Source: Fast + Epp, Timber Bay Design Tool

	Timber Volume Ratio	Podium on 1 <sup>st</sup> Floor?
IIIA – Option 1	0.73 CF / SF	Yes
IIIA – Option 2	0.74 CF / SF	Yes
IV-HT	0.51 CF / SF	Yes
IV-C	0.82 CF / SF	No

A general rule of thumb for efficient mass timber fiber volume is no higher than 0.75 CF per SF. Ratios in the 0.85 to 1.0 CF / SF range tend to become cost prohibitive



# Many ways to demonstrate connection fire protection: calculations, prescriptive NC, test results, others as approved by AHJ



2017 Glulam Beam to Column Connection Fire Tests under standard ASTM E119 timetemperature exposure









#### **MEP Layout & Integration**

#### Set Realistic Owner Expectations About Aesthetics

• MEP fully exposed with MT structure, or limited exposure?



#### **MEP Layout & Integration**

Smaller grid bays at central core (more head height)

• Main MEP trunk lines around core, smaller branches in exterior bays







Beam penetrations:

- If FRR = 0-hr, analyze structural impact of hole diameter only
- If FRR > 0-hr, account for charred hole diameter or firestop penetration



#### Option 1: MT penetration firestopping via tested products



#### Inventory of Fire Tested Penetrations in MT Assemblies

#### Table 3: North American Fire Tests of Penetrations and Fire Stops in CLT Assemblies



CLT Panel	Exposed Side Protection	Pen etrating Item	Penetrant Centered or Offset in Hole	Firestopping System Description	F Rating	T Rating	Stated Test Protocal	Source	Testing Lab
3-ply (78mm3.97*)	None	1.5° diameter data cable bun ch	Contered	3.5 in diameter hole. Mineral wool was installed in the lin. annular space around the data cables to a total depth of approximately 2 – 5/64 in. The remaining lin. annular space from the top of the mineral wool to the top of the floor assembly was filled with Hilti FS-One Max caulking.	I hour	0.5 hour	CANULC SI15	26	Intertek March 30, 2016
3-ply (78mm3.07*)	None	2* copper pipe	Centered	4.375 in diameter hole. Pipe wrap was installed around the copper pipe to a total depth of approximately 2 - 5/64 in. The remaining 1 in. annular space starting at the top of the mineral wool to the top of the floor assembly was filled with Hilti FS-One Max castking.	I hour	NA.	CANULC \$115	26	In tert ek March 30, 2016
3-ply (78mm 3.07*)	None	2.5* schod.40 pipe	Cen tered	4.92 in diamater hole. Pipe wap was installed around the schedule 40 pipe to a total depth of approximately 2 – 5/64 in. The remaining 1 in, an nular space starting at the top of the pipe wap to the top of the floor assembly was filled with Hitti FS-One Max caulking.	I hour	NA.	CANULC SI15	26	Intertek March 30, 2016
3-ply (78mm3.07*)	None	6" cast iron pipe	Centered	8.35 in diameter hule. Mineral wool was installed in the lin.annular space around the cast iron pipe to a total depth of approximately 2 – 5/64 in. The remaining lin. annular space starting at the top of the pipe wrap to the top of the floor assembly was filled with Hilti FS - One Max caulking.	I hour	NA.	CANULC \$115	26	Intertek March 30, 2016
3-ply (78mm3.07*)	None	Hilti 6 in drop in device. System No.: F-B-2049	Centered	9.01° diameter hole. Mineral wool was installed in the 1 – 1/4in. annular space around the drop-in device to a total depth of approximately 1 – 7/64in and the remaining lin, annular space from the top of the mineral wool to the top edge of the 9 – 1/64in, hole in the CLT was filled with Hilt i FS-One Max caulking.	l hour	0.75 hour	CANULC SI15	26	Intertek March 30, 2016
5-ply CLT (131 mm 5.16*)	None	1.5" diameter data cable bunch	Centered	3.5° diameter hole. Mineral wool was installed in the 1 in. annular space around the data cables to a total depth of approximately 4 – 5/32 in. The remaining 1 in. annular space from the top of the mineral wool to the top of the floor assembly was filled with Hilti FS-One Max caulking.	2 hours	1.5 hours	CANULC S115	26	Intertek March 30, 2016
5-ply CLT (131 mm 5.16*)	None	2* copper pipe	Centered	4.375 in diameter hole. Pipe wrap was installed around the copper pipe to a total depth of approximately 4 – 5/32 in. The remaining lin. annular space starting at the top of the mineral wool to the top of the floor as sembly was filled with Hilti FS-One Max caulking.	2 hours	NA.	CANULC \$115	26	Intertek March 30, 2016
5-ply CLT (131 mm 5.16*)	Nane	2.5° sched.40 pipe	Centered	4.92 in diameter hole. Fipe wrap was installed around the schedule 40 pipe to a total depth of approximately 4 – 5/32 in. The remaining 1 in. annular space starting at the top of the pipe wrap to the top of the floor assembly was filled with Hilti FS-One Max caulking.	2 hours	0.5 hour	CANULC S115	26	Intertek March 30, 2016
5-ply CLT (131 mm 5.16*)	None	6" cast iron pipe	Centered	8.35 in diameter hole. Mineral wool was installed in the lin.annular space around the cast iron pipe to a total depth of approximately 4 – 5/32 in. The remaining lin.annular space starting at the top of the pipe wrap to the top of the floor assembly was filled with Hilt i FS+One Max could ing.	2 hours	NA.	CANULC S115	26	Intertek March 30, 2016
5-ply CLT (131 mm 5.16*)	None	Hilti 6 în drop în device. System No.: F-B-2049	Centered	$9.01^{\circ}$ diameter hole. Mineral wool was installed in the $1 - 1.4$ in. annular space around the drop-in device to a total depth of approximately $1 - 7/64$ in and the remaining 1 in, annular space from the top of the mineral wool to the top edge of the $9 - 1/64$ in. hole in the CLT was filled with Hilt i FS-One Max caulking.	2 hours	1.5 hours	CANULC SI15	26	In tert ek March 30, 2016
5.ply (175mm6.#75*)	None	1* no min al PVC pipe	Centered	4.21 in diameter with a 3/4 in plywood reducer flush with the top of the slab reducing the opening to 2.28 in. Two wraps of Hilti CP 648-E W45/1-3/4" Firestop wrap strip at two locations with a 30 gaugested sleeve which extended from the top of the slab to 1 in below the slab. The first location was with the bottom of the wrap strip 3 in. from the bottom of the steel sleeve and the second was with the bottom of the wrap strip 3 in. from the bottom of the slab. The void between the steel sleeve and the CLT and between the steel sleeve and pipe at the top was filled with Roxul Safe mineral wool leaving a 3/4 in deep void at the voir of the assembly. Hilti IS-One Mas Intumescent Firestop Scalarit was applied to a depth of 3/4 in on the top of the assembly between the plywood and steel sleeve as well as the steel sleeve and pipe.	2 hours	2 hours	ASTM Et 14	24	QAI Laboratories March 3, 2017

Option 2: MT penetration firestopping of penetrations via engineering judgement details (contact firestop manufacturer)



1. 3-PLY CROSS LAMINATED TIMBER FLOOR ASSEMBLY (MINIMUM 3" THICK) (1-HR. FIRE-RATING).

- 2. HILTI CFS-DID FIRESTOP DROP-IN DEVICE INSERTED INTO OPENING (SEE TABLE BELOW) AND SECURED TO TOP SURFACE OF CROSS LAMINATED TIMBER FLOOR ASSEMBLY WITH THREE 1/4" x 1" LONG STEEL WOOD SCREWS WITH WASHERS.
- 3. MINIMUM 3" THICKNESS MINERAL WOOL (MIN. 4 PCF DENSITY) TIGHTLY PACKED, AND FLUSH WITH TOP AND BOTTOM SURFACE OF CFS-DID FIRESTOP DROP-IN DEVICE.
- 4. MINERAL WOOL (MIN. 4 PCF DENSITY) TIGHTLY PACKED, RECESSED TO ACCOMMODATE SEALANT, AND COMPLETELY FILLING SPACE BETWEEN CFS-DID FIRESTOP DROP-IN DEVICE AND PERIPHERY OF OPENING.
- 5. MINIMUM 1" DEPTH HILTI FS-ONE MAX INTUMESCENT FIRESTOP SEALANT BETWEEN CFS-DID FIRESTOP DROP IN DEVICE AND PERIPHERY OF OPENING.



- 1. MASS TIMBER WALL ASSEMBLY (MINIMUM 12" THICK) (1-HR. OR 2-HR. FIRE-RATING).
- 2. MAXIMUM 2" NOMINAL DIAMETER PVC PLASTIC PIPE (SCH 40).
- 3. MINIMUM 4" THICKNESS MINERAL WOOL (MIN. 4 PCF DENSITY) TIGHTLY PACKED AND RECESSED TO ACCOMMODATE SEALANT.
- 4. MINIMUM 3/4" DEPTH HILTI FS-ONE MAX INTUMESCENT FIRESTOP SEALANT.







Finish Floor if Applicable						 
Concrete/Gypsum Topping	_					
Acoustical Mat Product					11111	
	~					
CLT Panel		-	-			
No direct applied or hung ceiling —				-		







#### **Solutions Paper**



#### Acoustics and Mass Timber: Room-to-Room Noise Control

Richard McLain, PE, SE • Senior Technical Director • WoodWorks



The growing availability and code acceptance of mass timber—i.e., large solid wood panel products such as crosslaminated timber (CLT) and nai-laminated timber NLT) for floor, wall and root construction has given designers a low-carbon alternative to steel, concrete, and masony for many applications. However, the use of mass timber in multif-family and commercial buildings presents unique acoustic challenges. While laboratory measurements of the impact and airborne sound isolation of traditional building assemblies such as light wood-frame, steel and concrete are widely available, fewer resources exist that quantify the acoustic performance of mass timber assemblies. Additionally, one of the most desired aspects of mass timber construction is the ability to leave a building's structure exposed as finish, which creates the need for asymmetric assemblies. With careful design and detailing, mass timber buildings can meet the acoustic performance expectations of most building types.

#### http://www.woodworks.org/wp-content/uploads/wood solution paper-MASS-TIMBER-ACOUSTICS.pdf



#### Mass Timber Assembly Options: Walls

Mass timber panels can also be used for interior and exterior walls-both bearing and non-bearing. For interior walls, the need to conceal services such as electrical and plumbing is an added consideration. Common approaches include building a chase wall in front of the mass timber wall or installing gypsum wallboard on resilient channels that are attached to the mass timber wall. As with bare mass timber floor panels, bare mass timber walls don't typically provide adequate noise control, and chase walls also function as acoustical improvements. For example, a 3-ply CLT wall panel with a thickness of 3.07" has an STC rating of 33.4 In contrast, Figure 3 shows an interior CLT partition wall with chase walls on both sides. This assembly achieves an STC rating of 58, exceeding the IBC's acoustical requirements for multi-family construction. Other examples are included in the inventory of tested assemblies noted above.

#### Acoustical Differences between Mass Timber Panel Options

The majority of acoustically-tested mass timber assemblies include CLT. However, tests have also been done on other mass timber panel options such as NLT and dowel-taminated timber (DLT, as well as traditional heavy timber options such as tongue and groove decking. Most tests have concluded that CLT acoustical performance is slightly better than that of other mass timber options, largely because the crossorientation of laminations in a CLT panel limits sound flanking.

For those interested in comparing similar assemblies and mass timber panel types and thicknesses, the inventory noted above contains tested assemblies using CLT, NLT, glued-laminated timber panels (GLT), and tongue and groove decking.

#### Improving Performance by Minimizing Flanking

Even when the assemblies in a building are carefully designed and installed for high acoustical performance, consideration of llanking pather—in areas such as assembly intersections, beam-to-column/wall connections, and MEP penetrations—is necessary for a building to meet overall acoustical performance objectives.

One way to minimum flanking paths at these connections and interfaces is to use resilient connection isolition and sealant strips. These products are capable of resisting structural loads in compression between structural members and connections while providing station and breaking hard, direct connectors between members. In the context of the three methods for mirproving.

acoustical performance noted above, these strips act as decouplers. With artight connections, interfaces and penetrations, there is a much greater chance that the acoustic performance of a mass timber building will meet expectations.



Acoustical isolation strips

#### **Inventory of Tested Assemblies**

#### Table 1: CLT Floor Assemblies with Concrete/Gypsum Topping, Ceiling Side Exposed



	Finish Floor	if Applicable									
	Concrete/G	ypsum Topping							1.1		
	Accounting	Max Braduct									
	Acoustical				1						
			0								
									-		
	CLT Panel -		-		-	-	_				
	No direct a	pplied or hung ceiling			2						
CLT Panel	Concrete/Gypsum Topping	Acoustical N	coustical Mat Product Between CLT and Topping				Finish Floor		STC1	IIC1	Source
							None		47 <sup>2</sup> ASTC	47 <sup>2</sup> AIIC	
		Maxxon Acousti-Mat® 3/4			LVT			49 <sup>2</sup> AIIC			
1-1/2" Gyp-Co CLT 5-ply (6.875")					Carpet + Pad		-	75 <sup>2</sup> AIIC			
	To Contract M					LVT on	Acousti-Top*	-	52 <sup>2</sup> AIIC		
	1-1/2" Gyp-Crete*						Eng Wood on Acousti- Top®			51 <sup>2</sup> AIIC	1
		a set of the second				None		49 <sup>2</sup> ASTC	45 <sup>2</sup> AIIC		
		Maxxon Acousti-Mat <sup>®</sup> ¾ Premium			LVT		-	47 <sup>2</sup> AllC			
						LVT on Acousti-Top*		-	49 <sup>2</sup> AIIC	1	
		<u> </u>					None		456	396	15
							LVT		486	476	16
		USG SAM N25 Ultra			LVT Plus		486	496	58		
					Eng Wood		475	475	59		
						Carpet + Pad		456	675	60	
						Ceramic Tile		505	465	61	
1-1/2" []		2					None		456	425	15
	1-1/2" Levelrock®					IVT		486	445	16	

## **Early Design Decision Example**



#### 7-story, 84 ft tall multi-family building

- Parking & Retail on 1<sup>st</sup> floor, residential units on floors 2-7
- NFPA 13 sprinklers throughout
- Floor plate = 18,000 SF
- Total Building Area = 126,000 SF



#### **Early Design Decision Example**

7-story, multi-family building, typ. floor plan:





**Early Design Decision Example** 

**MT Construction Type Options:** 

- 7 stories of IV-C
- 5 stories of IIIA over 2 stories of IA podium
- 5 stories of IV-HT over 2 stories of IA podium







**Early Design Decision Example** 

#### **MT Construction Type Options:**

- <u>7 stories of IV-C</u>
- 5 stories of IIIA over 2 stories of IA podium
- 5 stories of IV-HT over 2 stories of IA podium

#### Implications of Type IV-C:

- 2 hr FRR, all exposed floor panels, beams, columns
- Likely will need at least 5-ply CLT / 2x6 NLT/DLT
- Efficient spans in the 14-17 ft range
- Efficient grids of that or multiples of that (i.e. 30x25, etc)
- No podium required
- CLT exterior walls permitted



#### **Early Design Decision Example**





#### **Early Design Decision Example**





## **Early Design Decision Example**





#### **Early Design Decision Example**









#### **Early Design Decision Example**

## Type IV-C Grid OptionsOption 2





**Early Design Decision Example** 

# Credit: Monte French Design Studio

#### **MT Construction Type Options:**

- 7 stories of IV-C
- <u>5 stories of IIIA over 2-stories of IA podium</u>
- 5 stories of IV-HT over 2 stories of IA podium

#### Implications of Type IIIA:

- 1-hr FRR
- Potential to use 3-ply or thin 5-ply CLT
- Efficient spans vary with panel thickness
- Efficient grids of that or multiples of that (i.e. 20x25, etc)
- 2-story Type IA podium required
- CLT exterior walls not permitted
# Key Early Design Decisions

**Early Design Decision Example** 

#### **MT Construction Type Options:**

- 7 stories of IV-C
- 5 stories of IIIA over 2 stories of IA podium
- <u>5 stories of IV-HT over 2 stories of IA podium</u>

### Type IV-HT in Group R Occupancy:

- Separation walls (fire partitions) and horizontal separation (horizontal assemblies) between dwelling units require a 1-hour rating.
- Floor panels require a 1-hour rating in addition to minimum sizes
- Essentially the same panel and grid options as IIIA

Ref. IBC 420.2, 420.3, 708.3, 711.2.4.3



### **Reduce Risk** Optimize Costs

- For the entire project team, not just builders
- Lots of reference documents



# Mass Timber Cost and Design Optimization Checklists

WoodWorks has developed the following checklists to assist in the design and cost optimization of mass timber projects. The *design optimization* checklists are intended for building designers (architects and engineers), but many of the topics should also be discussed with the fabricators and builders. The *cost optimization* checklists will help guide coordination between designers and builders (general contractors, construction managers, estimators, fabricators, installers, etc.) as they are estimating and making cost-related decisions on a mass timber project.

First Tech Federal Credit Union – Hillsboro, OR ARCHITECT Hacker ENGINEERIS Kamer Gehlen & Associates, Equilibrium Consulting CONTRACTOR Swinerton

Most resources listed in this paper can be found on the WoodWorks website. Please see the end notes for URLs.



#### Download Checklists at

www.woodworks.org

www.woodworks.org/wp-content/uploads/wood\_solution\_paper-Mass-Timber-Design-Cost-Optimization-Checklists.pdf

**Keys to Mass Timber Success: Know Your WHY** Design it as Mass Timber From the Start Leverage Manufacturer Capabilities **Understand Supply Chain Optimize Grid** Take Advantage of Prefabrication & Coordination **Expose the Timber Discuss Early with AHJ** Work with Experienced People Let WoodWorks Help for Free **Create Your Market Distinction** 

Images: Korb & Associates

# **Questions?**

# Jeff Peters, PE, CGC

#### **Regional Director | FL, AL & LA**

#### (386) 871-8808

Jeff.Peters@woodworks.org



901 East Sixth, Thoughtbarn-Delineate Studio, Leap!Structures, photo Casey Dunn

## **Copyright Materials**

This presentation is protected by US and International Copyright laws. Reproduction, distribution, display and use of the presentation without written permission of the speaker is prohibited.

© The Wood Products Council 2022

**Disclaimer:** The information in this presentation, including, without limitation, references to information contained in other publications or made available by other sources (collectively "information") should not be used or relied upon for any application without competent professional examination and verification of its accuracy, suitability, code compliance and applicability by a licensed engineer, architect or other professional. Neither the Wood Products Council nor its employees, consultants, nor any other individuals or entities who contributed to the information make any warranty, representative or guarantee, expressed or implied, that the information is suitable for any general or particular use, that it is compliant with applicable law, codes or ordinances, or that it is free from infringement of any patent(s), nor do they assume any legal liability or responsibility for the use, application of and/or reference to the information. Anyone making use of the information in any manner assumes all liability arising from such use.